



# Control block diagram of velocity control mode



## Wiring Example to the Connector CN X5

### Wiring Example of Velocity Control Mode





# Wiring to the connector, CN X5

## Interface Circuit

### Input Circuit


#### SI Connection to sequence input signals

- Connect to contacts of switches and relays, or open collector output transistors.
- When you use contact inputs, use the switches and relays for micro current to avoid contact failure.
- Make the lower limit voltage of the power supply (12 – 24V) as 11.4V or more in order to secure the primary current for photo-couplers.



#### AI Analog command input


- The analog command input goes through 3 routes, SPR/TRQR (Pin-14), CCWTL (Pin-16) and CWTL (Pin-18).
- Max. permissible input voltage to each input is  $\pm 10V$ . For input impedance of each input, refer to the right Fig.
- When you compose a simple command circuit using variable resistor (VR) and register R, connect as the right Fig. shows. When the variable range of each input is made as  $-10V - +10V$ , use VR with  $2k\Omega$ , B-characteristics,  $1/2W$  or larger, R with  $200\Omega$ ,  $1/2W$  or larger.
- A/D converter resolution of each command input is as follows.
  - (1) ADC1 : 16 bit (SPR/TRQR), (including 1bit for sign),  $\pm 10$
  - (2) ADC2 : 10 bit (CCWTL, CWTL),  $0 - 3.3V$



**Output Circuit**

**SO1 SO2 Sequence output circuit**


- The output circuit is composed of open collector transistor outputs in the Darlington connection, and connect to relays or photo-couplers.
- There exists collector to emitter voltage, VCE(SAT) of approx. 1V at transistor-ON, due to the Darlington connection of the output or. Note that normal TTL IC cannot be directly connected since it does not meet VIL.
- There are two types of output, one which emitter side of the output transistor is independent and is connectable individually, and the one which is common to - side of the control power supply (COM-).
- If a recommended primary current value of the photo-coupler is 10mA, decide the resistor value using the formula of the right Fig.



For the recommended primary current value, refer to the data sheet of apparatus or photo-coupler to be used.

**SO1 Line driver (Differential output) output**


- Feeds out the divided encoder outputs (A, B and Z-phase) in differential through each line driver.
- At the host side, receive these in line receiver. Install a terminal resistor (approx. 330Ω) between line receiver inputs without fail.
- These outputs are not insulated.



⊕ represents twisted pair.

**SO2 Open collector output**

- Feeds out the Z-phase signal among the encoder signals in open collector. This output is not insulated.
- Receive this output with high-speed photo couplers at the host side, since the pulse width of the Z-phase signal is narrow.



⊕ represents twisted pair.

**AO Analog monitor output**

- There are two outputs, the speed monitor signal output (SP) and the torque monitor signal output (IM)
- Output signal width is ±10V.
- The output impedance is 1kΩ. Pay an attention to the input impedance of the measuring instrument or the external circuit to be connected.


**<Resolution>**

(1) Speed monitor output (SP)

With a setup of 6V/3000r/min (Pr07=3), the resolution converted to speed is 8r/min/16mV.

(2) Torque monitor output (IM)

With a relation of 3V/rated torque (100%), the resolution converted to torque is 0.4%/12mV.



# Wiring to the connector, CN X5

## Input Signal and Pin No. of the Connector, CN X5

### Input Signals (common) and Their Functions

Title of signal	Pin No.	Symbol	Function	I/F circuit																														
Power supply for control signal (+)	7	COM+	<ul style="list-style-type: none"> <li>Connect + of the external DC power supply (12 to 24V).</li> <li>Use the power supply voltage of <math>12V \pm 5\% - 24V \pm 5\%</math></li> </ul>	–																														
Power supply for control signal (-)	41	COM-	<ul style="list-style-type: none"> <li>Connect – of the external DC power supply (12 to 24V).</li> <li>The power capacity varies depending on a composition of I/O circuit. 0.5A or more is recommended.</li> </ul>	–																														
CW over-travel inhibit input	8	CWL	<ul style="list-style-type: none"> <li>Use this input to inhibit a CW over-travel (CWL).</li> <li>Connect this so as to make the connection to COM- open when the moving portion of the machine over-travels the movable range toward CW.</li> <li>CWL input will be invalidated when you set up Pr04 (Setup of over-travel inhibit input) to 1.Default is "Invalid (1)".</li> <li>You can select the action when the CWL input is validated with the setup of up Pr66 (Sequence at over-travel inhibit). Default is "Emergency stop with dynamic brake".(Pr66=0)</li> </ul>	SI P.128																														
CCW over-travel inhibit input	9	CCWL	<ul style="list-style-type: none"> <li>Use this input to inhibit a CCW over-travel (CCWL).</li> <li>Connect this so as to make the connection to COM- open when the moving portion of the machine over-travels the movable range toward CCW.</li> <li>CWL input will be invalidated when you set up Pr04 (Setup of over-travel inhibit input) to 1.Default is "Invalid (1)".</li> <li>You can select the action when the CCWL input is validated with the setup of Pr66 (Sequence at over-travel inhibit). Default is "Emergency stop with dynamic brake".(Pr66=0)</li> </ul>	SI P.128																														
Speed zero clamp input	26	ZEROSPD	<ul style="list-style-type: none"> <li>Function varies depending on the control mode.</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td rowspan="6" style="text-align: center; vertical-align: middle;"><b>Velocity/ Torque control</b></td> <td colspan="3" style="text-align: center;">• Becomes to a speed-zero clamp input (ZEROSPD).</td> </tr> <tr> <th style="text-align: center;">Pr06</th> <th style="text-align: center;">Connection to COM-</th> <th style="text-align: center;">Content</th> </tr> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">–</td> <td style="text-align: center;">ZEROSPD input is invalid.</td> </tr> <tr> <td rowspan="2" style="text-align: center;">1</td> <td style="text-align: center;">open</td> <td style="text-align: center;">Speed command is 0</td> </tr> <tr> <td style="text-align: center;">close</td> <td style="text-align: center;">Normal action</td> </tr> <tr> <td rowspan="2" style="text-align: center;">2</td> <td style="text-align: center;">open</td> <td style="text-align: center;">Speed command is to CCW</td> </tr> <tr> <td style="text-align: center;">close</td> <td style="text-align: center;">Speed command is to CW.</td> </tr> <tr> <td colspan="3" style="text-align: center;">• In case Pr06 is 2 at torque control, ZERPSPD is invalid.</td> </tr> </table> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td rowspan="2" style="text-align: center; vertical-align: middle;"><b>Position/ Full-closed control</b></td> <td colspan="3" style="text-align: center;">• Becomes to an input of damping control switching (VS-SEL).</td> </tr> <tr> <td colspan="3" style="text-align: center;">• While Pr24 (Damping filter switching selection) is 1, the 1st damping filter (Pr2B, Pr2C) will be validated when you open this input, and the 2nd damping filter (Pr2D, Pr2E) will be validated when you connect this input to COM-.</td> </tr> </table>	<b>Velocity/ Torque control</b>	• Becomes to a speed-zero clamp input (ZEROSPD).			Pr06	Connection to COM-	Content	0	–	ZEROSPD input is invalid.	1	open	Speed command is 0	close	Normal action	2	open	Speed command is to CCW	close	Speed command is to CW.	• In case Pr06 is 2 at torque control, ZERPSPD is invalid.			<b>Position/ Full-closed control</b>	• Becomes to an input of damping control switching (VS-SEL).			• While Pr24 (Damping filter switching selection) is 1, the 1st damping filter (Pr2B, Pr2C) will be validated when you open this input, and the 2nd damping filter (Pr2D, Pr2E) will be validated when you connect this input to COM-.			SI P.128
<b>Velocity/ Torque control</b>	• Becomes to a speed-zero clamp input (ZEROSPD).																																	
	Pr06	Connection to COM-	Content																															
	0	–	ZEROSPD input is invalid.																															
	1	open	Speed command is 0																															
		close	Normal action																															
	2	open	Speed command is to CCW																															
close		Speed command is to CW.																																
• In case Pr06 is 2 at torque control, ZERPSPD is invalid.																																		
<b>Position/ Full-closed control</b>	• Becomes to an input of damping control switching (VS-SEL).																																	
	• While Pr24 (Damping filter switching selection) is 1, the 1st damping filter (Pr2B, Pr2C) will be validated when you open this input, and the 2nd damping filter (Pr2D, Pr2E) will be validated when you connect this input to COM-.																																	
Gain switching input or Torque limit switching input	27	GAIN  TL-SEL	<ul style="list-style-type: none"> <li>Function varies depending on the setups of Pr30 (2nd gain setup) and Pr03 (Selection of torque limit).</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th style="text-align: center;">Pr03</th> <th style="text-align: center;">Pr30</th> <th style="text-align: center;">Connection to COM-</th> <th style="text-align: center;">Content</th> </tr> <tr> <td rowspan="4" style="text-align: center;">0 – 2</td> <td rowspan="2" style="text-align: center;">0</td> <td style="text-align: center;">open</td> <td style="text-align: center;">Velocity loop : PI (Proportion/Integration) action</td> </tr> <tr> <td style="text-align: center;">close</td> <td style="text-align: center;">Velocity loop : P (Proportion) action</td> </tr> <tr> <td rowspan="3" style="text-align: center;">1</td> <td colspan="2" style="text-align: center;">when the setups of Pr31 and Pr36 are 2</td> <td style="text-align: center;">open</td> </tr> <tr> <td style="text-align: center;">close</td> <td colspan="2" style="text-align: center;">1st gain selection (Pr10,11,12,13 and 14)</td> </tr> <tr> <td colspan="2" style="text-align: center;">when the setups of Pr31 and Pr36 are other than 2</td> <td style="text-align: center;">invalid</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">–</td> <td colspan="2" style="text-align: center;"> <ul style="list-style-type: none"> <li>Input of torque limit switching (TL-SEL)</li> <li>Pr5E (Setup of 1st torque limit) will be validated when you open this input, and Pr5F (Setup of 2nd torque limit) will be validated when you connect this input to COM-.</li> </ul> </td> </tr> </table> <ul style="list-style-type: none"> <li>For details of 2nd gain switching function, refer to P.243 "Gain Switching Function" of Adjustment.</li> </ul>	Pr03	Pr30	Connection to COM-	Content	0 – 2	0	open	Velocity loop : PI (Proportion/Integration) action	close	Velocity loop : P (Proportion) action	1	when the setups of Pr31 and Pr36 are 2		open	close	1st gain selection (Pr10,11,12,13 and 14)		when the setups of Pr31 and Pr36 are other than 2		invalid	3	–	<ul style="list-style-type: none"> <li>Input of torque limit switching (TL-SEL)</li> <li>Pr5E (Setup of 1st torque limit) will be validated when you open this input, and Pr5F (Setup of 2nd torque limit) will be validated when you connect this input to COM-.</li> </ul>		SI P.128						
Pr03	Pr30	Connection to COM-	Content																															
0 – 2	0	open	Velocity loop : PI (Proportion/Integration) action																															
		close	Velocity loop : P (Proportion) action																															
	1	when the setups of Pr31 and Pr36 are 2		open																														
		close	1st gain selection (Pr10,11,12,13 and 14)																															
when the setups of Pr31 and Pr36 are other than 2		invalid																																
3	–	<ul style="list-style-type: none"> <li>Input of torque limit switching (TL-SEL)</li> <li>Pr5E (Setup of 1st torque limit) will be validated when you open this input, and Pr5F (Setup of 2nd torque limit) will be validated when you connect this input to COM-.</li> </ul>																																

## [Connection and setup of velocity control mode]

of signal	Pin No.	Symbol	Function	I/F circuit
Internal command speed selection 3 input	28	INTSPD3	<ul style="list-style-type: none"> <li>Function varies depending on the control mode.</li> </ul>	<div style="border: 1px solid black; padding: 2px;">SI</div> P.128
			<b>Position/ Full-closed control</b> <ul style="list-style-type: none"> <li>You can switch the numerator of electronic gear.</li> <li>By connecting to COM-, you can switch the numerator of electronic gear from Pr48 (1st numerator of electronic gear) to Pr49 (2nd numerator of electronic gear)</li> <li>For the selection of command division/multiplication, refer to the table of next page, "Numerator selection of command scaling"</li> </ul>	
			<b>Velocity control</b> <ul style="list-style-type: none"> <li>Input of internal speed selection 3 (INTSPD3).</li> <li>You can make up to 8-speed setups combining INH/INTSPD1 and CL/INTSPD2 inputs. For details of setup, refer to the table of P.131, "Selection of Internal Speed".</li> </ul>	
			<b>Torque control</b> <ul style="list-style-type: none"> <li>This input is invalid.</li> </ul>	
Servo-ON input	29	SRV-ON	<ul style="list-style-type: none"> <li>Turns to Servo-ON status by connecting this input to COM-.</li> <li>Turns to Servo-OFF status by opening connection to COM-, and current to the motor will be shut off.</li> <li>You can select the dynamic brake action and the deviation counter clearing action at Servo-OFF with Pr69 (Sequence at Servo-OFF).</li> </ul> <p><b>&lt;Caution&gt;</b></p> <ol style="list-style-type: none"> <li>Servo-ON input becomes valid approx. 2 sec after power-on. (see P.42, "Timing Chart" of Preparation.)</li> <li>Never run/stop the motor with Servo-ON/OFF.</li> <li>After shifting to Servo-ON, allow 100ms or longer pause before entering the pulse command.</li> </ol>	<div style="border: 1px solid black; padding: 2px;">SI</div> P.128

### • Selection of Internal Speed

Connector Pin No. of X5			Pr05, Internal/external switching of speed setup			
Pin-33 INTSPD1(INH)	Pin-30 INTSPD2(CL)	Pin-28 INTSPD3(DIV)	0	1	2	3
open	open	open	Analog speed command (CN X5, Pin-14)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)
short	open	open	Analog speed command (CN X5, Pin-14)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)
open	short	open	Analog speed command (CN X5, Pin-14)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)
short	short	open	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)
open	open	short	Analog speed command (CN X5, Pin-14)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)	5th speed of speed setup (Pr74)
short	open	short	Analog speed command (CN X5, Pin-14)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)	6th speed of speed setup (Pr75)
open	short	short	Analog speed command (CN X5, Pin-14)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)	7th speed of speed setup (Pr76)
short	short	short	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)	Analog speed command (CN X5, Pin-14)	8th speed of speed setup (Pr77)

# Wiring to the connector, CN X5

Title of signal	Pin No.	Symbol	Function	I/F circuit												
Selection 2 input of internal command speed	30	INTSPD2	<ul style="list-style-type: none"> <li>Function varies depending on the control mode.</li> </ul>	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 1px;">SI</span>                      P.128                 </div>												
			<div style="border: 1px solid black; padding: 2px;"> <b>Position/ Full-closed control</b> <ul style="list-style-type: none"> <li>Input (CL) which clears the positional deviation counter and full-closed deviation counter.</li> <li>You can clear the counter of positional deviation and full-closed deviation by connecting this to COM-.</li> <li>You can select the clearing mode with Pr4E (Counter clear input mode)..</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Pr4E</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Clears the counter of positional deviation and full-closed deviation while CL is connected to COM-.</td> </tr> <tr> <td style="text-align: center;">1 [Default]</td> <td>Clears the counter of positional deviation and full-closed deviation only once by connecting CL to COM- from open status.</td> </tr> <tr> <td style="text-align: center;">2</td> <td>CL is invalid</td> </tr> </tbody> </table> </div>		Pr4E	Content	0	Clears the counter of positional deviation and full-closed deviation while CL is connected to COM-.	1 [Default]	Clears the counter of positional deviation and full-closed deviation only once by connecting CL to COM- from open status.	2	CL is invalid				
			Pr4E		Content											
			0		Clears the counter of positional deviation and full-closed deviation while CL is connected to COM-.											
1 [Default]	Clears the counter of positional deviation and full-closed deviation only once by connecting CL to COM- from open status.															
2	CL is invalid															
<div style="border: 1px solid black; padding: 2px;"> <b>Velocity control</b> <ul style="list-style-type: none"> <li>Input of selection 2 of internal command speed (INTSPD2)</li> <li>You can make up to 8-speed setups combining INH/INTSPD1 and CL/INTSPD3 inputs. For details of setup, refer to the table in P.131, "Selection of Internal Speed" of Velocity Control Mode.</li> </ul> </div>																
<div style="border: 1px solid black; padding: 2px;"> <b>Torque control</b> <ul style="list-style-type: none"> <li>This input is invalid.</li> </ul> </div>																
Alarm clear input	31	A-CLR	<ul style="list-style-type: none"> <li>You can release the alarm status by connecting this to COM- for more than 120ms.</li> <li>The deviation counter will be cleared at alarm clear.</li> <li>There are some alarms which cannot be released with this input. For details, refer to P.252, "Protective Function " of When in Trouble.</li> </ul>	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 1px;">SI</span>                      P.128                 </div>												
Servo-ON input	32	C-MODE	<ul style="list-style-type: none"> <li>You can switch the control mode as below by setting up Pr02 (Control mode setup) to 3-5.</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 25%;">Pr02 setup</th> <th style="width: 35%;">Open (1st)</th> <th style="width: 40%;">Connection to COM- (2nd)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Position control</td> <td style="text-align: center;">Velocity control</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">Position control</td> <td style="text-align: center;">Torque control</td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">Velocity control</td> <td style="text-align: center;">Torque control</td> </tr> </tbody> </table>	Pr02 setup	Open (1st)	Connection to COM- (2nd)	3	Position control	Velocity control	4	Position control	Torque control	5	Velocity control	Torque control	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 1px;">SI</span>                      P.128                 </div>
			Pr02 setup	Open (1st)	Connection to COM- (2nd)											
			3	Position control	Velocity control											
4	Position control	Torque control														
5	Velocity control	Torque control														
<p><b>&lt;Caution&gt;</b>                      Depending on how the command is given at each control mode, the action might change rapidly when switching the control mode with C-MODE. Pay an extra attention.</p>																
Selection 1 input of internal command speed	33	INTSPD1	<ul style="list-style-type: none"> <li>Function varies depending on the control mode.</li> </ul>	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 1px;">SI</span>                      P.128                 </div>												
			<div style="border: 1px solid black; padding: 2px;"> <b>Position/ Full closed control</b> <ul style="list-style-type: none"> <li>Inhibition input of command pulse input (INH)</li> <li>Ignores the position command pulse by opening the connection to COM-</li> <li>You can invalidate this input with Pr43 (Invalidation of command pulse inhibition input)</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Pr43</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>INH is valid.</td> </tr> <tr> <td style="text-align: center;">1(Default)</td> <td>INH is valid.</td> </tr> </tbody> </table> </div>		Pr43	Content	0	INH is valid.	1(Default)	INH is valid.						
			Pr43		Content											
			0		INH is valid.											
1(Default)	INH is valid.															
<div style="border: 1px solid black; padding: 2px;"> <b>Velocity control</b> <ul style="list-style-type: none"> <li>Selection 1 input of internal command speed (INTSPD1)</li> <li>You can make up to 8-speed setups combining INH/INTSPD2 and CL/INTSPD3 inputs. For details of the setup, refer to the table of P.131, "Selection of Internal Speed" of Velocity Control Mode.</li> </ul> </div>																
<div style="border: 1px solid black; padding: 2px;"> <b>Torque control</b> <ul style="list-style-type: none"> <li>This input is invalid.</li> </ul> </div>																

# [Connection and setup of velocity control mode]

## Input Signals (Analog Command) and Their Functions

Title of signal	Pin No.	Symbol	Function	I/F circuit						
<b>Speed command input</b>	<b>14</b>	<b>SPR</b>	<ul style="list-style-type: none"> <li>Function varies depending on control mode.</li> </ul>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">AI</div> P.128						
			<b>Pr02</b>		<b>Control mode</b>	<b>Function</b>				
			1		<b>Velocity control</b>	<ul style="list-style-type: none"> <li>Input of external speed command (SPR) when the velocity control is selected.</li> <li>Set up the gain, polarity, offset and filter of the Speed command with;                             <ul style="list-style-type: none"> <li>Pr50 (Speed command input gain)</li> <li>Pr51 (Speed command input reversal)</li> <li>Pr52 (Speed command offset)</li> <li>Pr57 (Speed command filter setup)</li> </ul> </li> </ul>				
			3		<b>Position/Velocity</b>					
		5	<b>Velocity/Torque</b>							
		5	<b>Position/Torque</b>	<ul style="list-style-type: none"> <li>Function varies depending on Pr5B (Selection of torque command)</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr style="background-color: #f2f2f2;"> <th style="width: 10%;">Pr5B</th> <th style="width: 90%;">Content</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td> <ul style="list-style-type: none"> <li>This input becomes invalid.</li> </ul> </td> </tr> <tr> <td style="text-align: center;">1</td> <td> <ul style="list-style-type: none"> <li>Speed limit (SPL) will be selected.</li> <li>Set up velocity limit (SPL) gain, offset and filter with;                             <ul style="list-style-type: none"> <li>Pr50 (Speed command input gain)</li> <li>Pr52 (Speed command offset)</li> <li>Pr57 (Speed command filter setup)</li> </ul> </li> </ul> </td> </tr> </tbody> </table>	Pr5B	Content	0	<ul style="list-style-type: none"> <li>This input becomes invalid.</li> </ul>	1	<ul style="list-style-type: none"> <li>Speed limit (SPL) will be selected.</li> <li>Set up velocity limit (SPL) gain, offset and filter with;                             <ul style="list-style-type: none"> <li>Pr50 (Speed command input gain)</li> <li>Pr52 (Speed command offset)</li> <li>Pr57 (Speed command filter setup)</li> </ul> </li> </ul>
Pr5B	Content									
0	<ul style="list-style-type: none"> <li>This input becomes invalid.</li> </ul>									
1	<ul style="list-style-type: none"> <li>Speed limit (SPL) will be selected.</li> <li>Set up velocity limit (SPL) gain, offset and filter with;                             <ul style="list-style-type: none"> <li>Pr50 (Speed command input gain)</li> <li>Pr52 (Speed command offset)</li> <li>Pr57 (Speed command filter setup)</li> </ul> </li> </ul>									
		Others	<b>Other control mode</b>	<ul style="list-style-type: none"> <li>This input is invalid.</li> </ul>						

•The resolution of the A/D converter used in this input is 16 bit (including 1 bit for sign).  
 $\pm 32767$  (LSB) =  $\pm 10$ [V], 1[LSB]  $\cong$  0.3[mV]

\*Function becomes valid when the control mode with underline (  /  )

**<Remark>**

Do not apply voltage exceeding  $\pm 10$ V to analog command input of SPR

# Wiring to the connector, CN X5

Title of signal	Pin No.	Symbol	Function	I/F circuit																		
CCW-Torque limit input	16	CCWTL	<ul style="list-style-type: none"> <li>Function varies depending on Pr02 (Control mode setup).</li> </ul> <table border="1"> <thead> <tr> <th>Pr02</th> <th>Control mode</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td rowspan="2">2 4</td> <td rowspan="2"><u>Torque Control</u> <u>Position/Torque</u></td> <td> <ul style="list-style-type: none"> <li>Function varies depending on Pr5B (Selection of torque command)</li> </ul> <table border="1"> <thead> <tr> <th>Pr5B</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>This input becomes invalid.</td> </tr> <tr> <td>1</td> <td> <ul style="list-style-type: none"> <li>Torque command input (TRQR) will be selected.</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul> </td> </tr> </tbody> </table> </td> </tr> <tr> <td>5</td> <td><u>Velocity/Torque</u></td> <td> <ul style="list-style-type: none"> <li>Becomes to the torque command input (TRQR).</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul> </td> </tr> <tr> <td>4 5 Other</td> <td><u>Position/Torque</u> <u>Velocity/Torque</u> <b>Other control mode</b></td> <td> <ul style="list-style-type: none"> <li>Becomes to the analog torque limit input to CCW (CCWTL).</li> <li>Limit the CCW-torque by applying positive voltage (0 to +10V) (Approx.+3V/rated torque)</li> <li>Invalidate this input by setting up Pr03 (Torque limit selection) to other than 0.</li> </ul> </td> </tr> </tbody> </table>	Pr02	Control mode	Function	2 4	<u>Torque Control</u> <u>Position/Torque</u>	<ul style="list-style-type: none"> <li>Function varies depending on Pr5B (Selection of torque command)</li> </ul> <table border="1"> <thead> <tr> <th>Pr5B</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>This input becomes invalid.</td> </tr> <tr> <td>1</td> <td> <ul style="list-style-type: none"> <li>Torque command input (TRQR) will be selected.</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul> </td> </tr> </tbody> </table>	Pr5B	Content	0	This input becomes invalid.	1	<ul style="list-style-type: none"> <li>Torque command input (TRQR) will be selected.</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul>	5	<u>Velocity/Torque</u>	<ul style="list-style-type: none"> <li>Becomes to the torque command input (TRQR).</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul>	4 5 Other	<u>Position/Torque</u> <u>Velocity/Torque</u> <b>Other control mode</b>	<ul style="list-style-type: none"> <li>Becomes to the analog torque limit input to CCW (CCWTL).</li> <li>Limit the CCW-torque by applying positive voltage (0 to +10V) (Approx.+3V/rated torque)</li> <li>Invalidate this input by setting up Pr03 (Torque limit selection) to other than 0.</li> </ul>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">AI</div> P.128
			Pr02	Control mode	Function																	
2 4	<u>Torque Control</u> <u>Position/Torque</u>	<ul style="list-style-type: none"> <li>Function varies depending on Pr5B (Selection of torque command)</li> </ul> <table border="1"> <thead> <tr> <th>Pr5B</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>This input becomes invalid.</td> </tr> <tr> <td>1</td> <td> <ul style="list-style-type: none"> <li>Torque command input (TRQR) will be selected.</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul> </td> </tr> </tbody> </table>	Pr5B	Content	0	This input becomes invalid.	1	<ul style="list-style-type: none"> <li>Torque command input (TRQR) will be selected.</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul>														
		Pr5B	Content																			
0	This input becomes invalid.																					
1	<ul style="list-style-type: none"> <li>Torque command input (TRQR) will be selected.</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul>																					
5	<u>Velocity/Torque</u>	<ul style="list-style-type: none"> <li>Becomes to the torque command input (TRQR).</li> <li>Set up the gain and polarity of the command with;                             <ul style="list-style-type: none"> <li>Pr5C (Torque command input gain)</li> <li>Pr5D (Torque command input reversal)</li> </ul> </li> <li>Offset and filter cannot be set up.</li> </ul>																				
4 5 Other	<u>Position/Torque</u> <u>Velocity/Torque</u> <b>Other control mode</b>	<ul style="list-style-type: none"> <li>Becomes to the analog torque limit input to CCW (CCWTL).</li> <li>Limit the CCW-torque by applying positive voltage (0 to +10V) (Approx.+3V/rated torque)</li> <li>Invalidate this input by setting up Pr03 (Torque limit selection) to other than 0.</li> </ul>																				
<ul style="list-style-type: none"> <li>Resolution of A/D converter used in this input is 16 bit (including 1 bit for sign). ± 511 [LSB] = ± 11.9[V], 1 [LSB] ≙ 23[mV]</li> </ul>																						
CW-Torque limit input	18	CWTL	<ul style="list-style-type: none"> <li>Function varies depending on Pr02 (Control mode setup).</li> </ul> <table border="1"> <thead> <tr> <th>Pr02</th> <th>Control mode</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>2 4 5</td> <td><u>Torque control</u> <u>Position/Torque</u> <u>Velocity/Torque</u></td> <td> <ul style="list-style-type: none"> <li>This input becomes invalid when the torque control is selected.</li> </ul> </td> </tr> <tr> <td>4 5 Other</td> <td><u>Position/Torque</u> <u>Velocity/Torque</u> <b>Other control mode</b></td> <td> <ul style="list-style-type: none"> <li>Becomes to the analog torque limit input to CW (CWTL).</li> <li>Limit the CW-torque by applying negative voltage (0 – -10V) (Approx.+3V/rated torque).</li> <li>Invalidate this input by setting up Pr03 (Torque limit selection) to other than 0.</li> </ul> </td> </tr> </tbody> </table>	Pr02	Control mode	Function	2 4 5	<u>Torque control</u> <u>Position/Torque</u> <u>Velocity/Torque</u>	<ul style="list-style-type: none"> <li>This input becomes invalid when the torque control is selected.</li> </ul>	4 5 Other	<u>Position/Torque</u> <u>Velocity/Torque</u> <b>Other control mode</b>	<ul style="list-style-type: none"> <li>Becomes to the analog torque limit input to CW (CWTL).</li> <li>Limit the CW-torque by applying negative voltage (0 – -10V) (Approx.+3V/rated torque).</li> <li>Invalidate this input by setting up Pr03 (Torque limit selection) to other than 0.</li> </ul>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">AI</div> P.128									
			Pr02	Control mode	Function																	
2 4 5	<u>Torque control</u> <u>Position/Torque</u> <u>Velocity/Torque</u>	<ul style="list-style-type: none"> <li>This input becomes invalid when the torque control is selected.</li> </ul>																				
4 5 Other	<u>Position/Torque</u> <u>Velocity/Torque</u> <b>Other control mode</b>	<ul style="list-style-type: none"> <li>Becomes to the analog torque limit input to CW (CWTL).</li> <li>Limit the CW-torque by applying negative voltage (0 – -10V) (Approx.+3V/rated torque).</li> <li>Invalidate this input by setting up Pr03 (Torque limit selection) to other than 0.</li> </ul>																				
<ul style="list-style-type: none"> <li>Resolution of A/D converter used in this input is 16 bit (including 1 bit for sign). ± 511 [LSB] = ± 11.9[V], 1 [LSB] ≙ 23[mV]</li> </ul>																						

\*Function becomes valid when the control mode with underline (  /  )

## <Remark>

Do not apply voltage exceeding ±10V to analog command input of CWTL and CCWTL

Output signal and Pin No. of the Connector, CN X5

Output Signals (Common) and Their Functions

Title of signal	Pin No	Symbol	Function	I/F circuit							
External brake release signal	11	BRKOFF+	<ul style="list-style-type: none"> <li>Feeds out the timing signal which activates the electromagnetic brake of the motor.</li> <li>Turns the output transistor ON at the release timing of the electromagnetic brake.</li> <li>You can set up the output timing of this signal with Pr6A (Setup of mechanical brake action at stall) and Pr6B (Setup of mechanical brake action at motion). For details, refer to P42, "Timing Chart" of Preparation.)</li> </ul>	SO1 P.129							
	10	BRKOFF-									
Servo-Ready output	35	S-RDY+	<ul style="list-style-type: none"> <li>This signal shows that the driver is ready to be activated.</li> <li>Output transistor turns ON when both control and main power are ON but not at alarm status.</li> </ul>	SO1 P.129							
	34	S-RDY-									
Servo-Alarm output	37	ALM+	<ul style="list-style-type: none"> <li>This signal shows that the driver is in alarm status..</li> <li>Output transistor turns ON when the driver is at normal status, and turns OFF at alarm status.</li> </ul>	SO1 P.129							
	36	ALM-									
Positioning complete (In-position)	39 38	AT-SPEED+	<ul style="list-style-type: none"> <li>Function varies depending on the control mode.</li> </ul>	SO1 P.129							
		AT-SPEED-			<table border="1"> <tr> <td>Position control</td> <td> <ul style="list-style-type: none"> <li>Output of positioning complete (COIN)</li> <li>The output transistor will turn ON when the absolute value of the position deviation pulse becomes smaller than the setup value of Pr60 (Positioning complete range).</li> <li>You can select the feeding out method with Pr63 (Setup of positioning complete output).</li> </ul> </td> </tr> <tr> <td>Full-closed control</td> <td> <ul style="list-style-type: none"> <li>Output of full-closed positioning complete (EX-COIN)</li> <li>The output transistor will turn ON when the absolute value of full-closed-position deviation pulse becomes smaller than the setup value of Pr60 (Positioning complete range).</li> <li>You can select the feeding out method with Pr63 (Setup of positioning complete output).</li> </ul> </td> </tr> <tr> <td>Velocity/Torque control</td> <td> <ul style="list-style-type: none"> <li>Output at-speed (speed arrival) (AT-SPEED)</li> <li>The output transistor will turn ON when the actual motor speed exceeds the setup value of Pr62 (In-speed).</li> </ul> </td> </tr> </table>	Position control	<ul style="list-style-type: none"> <li>Output of positioning complete (COIN)</li> <li>The output transistor will turn ON when the absolute value of the position deviation pulse becomes smaller than the setup value of Pr60 (Positioning complete range).</li> <li>You can select the feeding out method with Pr63 (Setup of positioning complete output).</li> </ul>	Full-closed control	<ul style="list-style-type: none"> <li>Output of full-closed positioning complete (EX-COIN)</li> <li>The output transistor will turn ON when the absolute value of full-closed-position deviation pulse becomes smaller than the setup value of Pr60 (Positioning complete range).</li> <li>You can select the feeding out method with Pr63 (Setup of positioning complete output).</li> </ul>	Velocity/Torque control	<ul style="list-style-type: none"> <li>Output at-speed (speed arrival) (AT-SPEED)</li> <li>The output transistor will turn ON when the actual motor speed exceeds the setup value of Pr62 (In-speed).</li> </ul>
		Position control			<ul style="list-style-type: none"> <li>Output of positioning complete (COIN)</li> <li>The output transistor will turn ON when the absolute value of the position deviation pulse becomes smaller than the setup value of Pr60 (Positioning complete range).</li> <li>You can select the feeding out method with Pr63 (Setup of positioning complete output).</li> </ul>						
Full-closed control	<ul style="list-style-type: none"> <li>Output of full-closed positioning complete (EX-COIN)</li> <li>The output transistor will turn ON when the absolute value of full-closed-position deviation pulse becomes smaller than the setup value of Pr60 (Positioning complete range).</li> <li>You can select the feeding out method with Pr63 (Setup of positioning complete output).</li> </ul>										
Velocity/Torque control	<ul style="list-style-type: none"> <li>Output at-speed (speed arrival) (AT-SPEED)</li> <li>The output transistor will turn ON when the actual motor speed exceeds the setup value of Pr62 (In-speed).</li> </ul>										
Zero-speed detection output signal	12 (41)	ZSP (COM-)	<ul style="list-style-type: none"> <li>Content of the output signal varies depending on Pr0A (Selection of ZSP output).</li> <li>Default is 1, and feeds out the zero speed detection signal.</li> <li>For details, see the table below, "Selection of TLC,ZSP output".</li> </ul>	SO2 P.129							
Torque in-limit signal output	40 (41)	TLC (COM-)	<ul style="list-style-type: none"> <li>Content of the output signal varies depending on Pr09 (Selection of TLC output).</li> <li>Default is 1, and feeds out the torque in-limit signal.</li> <li>For details, see the table below, "Selection of TLC,ZSP output".</li> </ul>	SO2 P.129							

• Selection of TCL and ZSP outputs

	X5 TLC : Output of Pin-40	X5 ZSP : Output of Pin-12
0	<ul style="list-style-type: none"> <li><b>Torque in-limit output (Default of X5 TLC Pr09)</b> The output transistor turns ON when the torque command is limited by the torque limit during Servo-ON.</li> </ul>	
1	<ul style="list-style-type: none"> <li><b>Zero-speed detection output (Default of X5 ZSP Pr0A)</b> The output transistor turns ON when the motor speed falls under the preset value with Pr61.</li> </ul>	
2	<ul style="list-style-type: none"> <li><b>Alarm signal output</b> The output transistor turns ON when either one of the alarms is triggered, over-regeneration alarm, overload alarm, battery alarm, fan-lock alarm or external scale alarm.</li> </ul>	
3	<ul style="list-style-type: none"> <li><b>Over-regeneration alarm</b> The output transistor turns ON when the regeneration exceeds 85% of the alarm trigger level of the regenerative load protection.</li> </ul>	
4	<ul style="list-style-type: none"> <li><b>Over-load alarm</b> The output transistor turns ON when the load exceeds 85% of the alarm trigger level of the overload alarm.</li> </ul>	
5	<ul style="list-style-type: none"> <li><b>Battery alarm</b> The output transistor turns ON when the battery voltage for absolute encoder falls lower than approx. 3.2V.</li> </ul>	
6	<ul style="list-style-type: none"> <li><b>Fan-lock alarm</b> The output transistor turns ON when the fan stalls for longer than 1s.</li> </ul>	
7	<ul style="list-style-type: none"> <li><b>External scale alarm</b> The output transistor turns ON when the external scale temperature exceeds 65°, or signal intensity is not enough (adjustment on mounting is required). Valid only at the full-closed control.</li> </ul>	
8	<ul style="list-style-type: none"> <li><b>In-speed (Speed coincidence) output</b> The output transistor turns ON when the difference between the actual motor speed and the speed command before acceleration/deceleration reaches within the preset range with Pr61. Valid only at the velocity and torque control.</li> </ul>	

# Wiring to the connector, CN X5

## Output Signals (Pulse Train) and Their Functions


title of signal	Pin No	Symbol	Function	I/F circuit
A-phase output	21	OA +	<ul style="list-style-type: none"> <li>• Feeds out the divided encoder signal or external scale signal (A, B, Z-phase) in differential. (equivalent to RS422)</li> <li>• You can set up the division ratio with Pr44 (Numerator of pulse output division) and Pr45 (Denominator of pulse output division)</li> <li>• You can select the logic relation between A-phase and B-phase, and the output source with Pr46 (Reversal of pulse output logic).</li> <li>• When the external scale is made as an output source, you can set up the interval of Z-phase pulse output with Pr47 (Setup of external scale Z-phase).</li> <li>• Ground for line driver of output circuit is connected to signal ground (GND) and is not insulated.</li> <li>• Max. output frequency is 4Mpps (after quadrupled)</li> </ul>	<div style="border: 1px solid black; padding: 2px;">PO1</div> P.129
	22	OA -		
B-phase output	48	OB +		
	49	OB -		
Z-phase output	23	OZ +		
	24	OZ -		
Z-phase output	19	CZ	<ul style="list-style-type: none"> <li>• Open collector output of Z-phase signal</li> <li>• The emitter side of the transistor of the output circuit is connected to the signal ground (GND) and is not insulated.</li> </ul>	<div style="border: 1px solid black; padding: 2px;">PO2</div> P.129

### <Note>

#### • When the output source is the encoder

- If the encoder resolution  $\times \frac{\text{Pr44}}{\text{Pr45}}$  is multiple of 4, Z-phase will be fed out synchronizing with A-phase.

In other case, the Z-phase width will be equal to the encoder resolution, and will not synchronize with A-phase because of narrower width than that of A-phase.



- In case of the 5-wire, 2500P/r incremental encoder, the signal sequence might not follow the above fig. until the first Z-phase is fed out. When you use the pulse output as the control signal, rotate the motor one revolution or more to make sure that the Z-phase is fed out at least once before using.

**Output Signals (Analog) and Their Functions**

Title of signal	Pin No	Symbol	Function	I/F circuit		
Torque monitor signal output	42	IM	<ul style="list-style-type: none"> <li>The content of output signal varies depending on Pr08 (Torque monitor (IM) selection).</li> <li>You can set up the scaling with Pr08 value.</li> </ul>	<div style="border: 1px solid black; padding: 2px;">AO</div> P.129		
			<b>Pr08</b>		<b>Content of signal</b>	<b>Function</b>
			0, 11, 12		<b>Torque command</b>	<ul style="list-style-type: none"> <li>Feeds out the voltage in proportion to the motor torque command with polarity.</li> <li>+ : generates CCW torque</li> <li>- : generates CW torque</li> </ul>
			1 – 5		<b>Positional deviation</b>	<ul style="list-style-type: none"> <li>Feeds out the voltage in proportion to the positional deviation pulse counts with polarity.</li> <li>+ : positional command to CCW of motor position</li> <li>- : positional command to CW of motor position</li> </ul>
6 – 10	<b>Full-closed deviation</b>	<ul style="list-style-type: none"> <li>Feeds out the voltage in proportion to the full-closed deviation pulse counts with polarity.</li> <li>+ : positional command to CCW of external scale position</li> <li>- : positional command to CW of external scale position</li> </ul>				
Speed monitor signal output	43	SP	<ul style="list-style-type: none"> <li>The content of the output signal varies depending on Pr07 (Speed monitor (IM) selection).</li> <li>You can set up the scaling with Pr07 value.</li> </ul>	<div style="border: 1px solid black; padding: 2px;">AO</div> P.129		
			<b>Pr07</b>		<b>Control mode</b>	<b>Function</b>
			0 – 4		<b>Motor speed</b>	<ul style="list-style-type: none"> <li>Feeds out the voltage in proportion to the motor speed with polarity.</li> <li>+ : rotates to CCW</li> <li>- : rotates to CW</li> </ul>
			5 – 9		<b>Command speed</b>	<ul style="list-style-type: none"> <li>Feeds out the voltage in proportion to the command speed with polarity.</li> <li>+ : rotates to CCW</li> <li>- : rotates to CW</li> </ul>

**Output Signals (Others) and Their Functions**

Title of signal	Pin No	Symbol	Function	I/F circuit
Signal ground	13,15, 17,25	GND	<ul style="list-style-type: none"> <li>Signal ground</li> <li>This output is insulated from the control signal power (COM-) inside of the driver.</li> </ul>	–
Frame ground	50	FG	<ul style="list-style-type: none"> <li>This output is connected to the earth terminal inside of the driver.</li> </ul>	–

# Trial Run (JOG run) at Velocity Control Mode

## Inspection Before Trial Run

### (1) Wiring inspection

- Miswiring  
(Especially power input/motor output)
- Short/Earth
- Loose connection

### (2) Check of power/voltage


- Rated voltage

### (3) Fixing of the motor

- Unstable fixing

### (4) Separation from mechanical system

### (5) Release of the brake




**Trial Run by Connecting the Connector, CN X5**

- 1) Connect the CN X5.
- 2) Enter the power (DC12-24V) to control signal (COM+, COM-)
- 3) Enter the power to the driver.
- 4) Confirm the default values of parameters.
- 5) Connect the Servo-ON input (SRV-ON, CN X5, Pin-29) and COM- (CN X5, Pin-14) to turn to Servo-ON and energize the motor.
- 6) Close the speed zero clamp input (ZEROSPD) and apply DC voltage between velocity command input , SPR (CN X5, Pin-14) and GND (CN X5, Pin-15), and gradually increase from 0V to confirm the motor runs.
- 7) Confirm the motor rotational speed in monitor mode.
  - whether the rotational speed is per the setup or not.
  - whether the motor stops with zero command or not.
- 8) If the motor does rotate at a micro speed with command voltage of 0, correct the command voltage referring to P.74, "Automatic offset adjustment" of Preparation.
- 9) When you want to change the rotational speed and direction, set up the following parameters again.

Pr50 : Speed command input gain      ] Refer to P.152, "Parameter Setup"  
 Pr51 : Speed command input reversal   ] (Parameters for Velocity/Torque Control)

10) If the motor does not run correctly, refer to P.68, "Display of Factor for No-Motor Running" of Preparation.

**Wiring Diagram**



**Parameter**

PrNo.	Title	Setup value
02	Setup of control mode	1
04	Invalidation of over-travel inhibit input	1
06	Selection of ZEROSPD input	1
50	Velocity command gain	Set up as required
51	Velocity command reversal	
52	Velocity command offset	
57	Setup of velocity command filter	


**Input signal status**

No.	Title of signal	Monitor display
0	Servo-ON	+A
5	Speed zero clamp	-

# Real-Time Auto-Gain Tuning

## Outline

The driver estimates the load inertia of the machine in real time, and automatically sets up the optimum gain responding to the result. Also the driver automatically suppress the vibration caused by the resonance with an adaptive filter.



## Applicable Range

- Real-time auto-gain tuning is applicable to all control modes.

### Caution

Real-time auto-gain tuning may not be executed properly under the conditions described in the right table. In these cases, use the normal mode auto-gain tuning (refer to P.236 of Adjustment), or execute a manual gain tuning. (refer to P.240, of Adjustment)

	Conditions which obstruct real-time auto-gain tuning
<b>Load inertia</b>	<ul style="list-style-type: none"> <li>• Load is too small or large compared to rotor inertia. (less than 3 times or more than 20 times)</li> <li>• Load inertia change too quickly. (10 [s] or less)</li> </ul>
<b>Load</b>	<ul style="list-style-type: none"> <li>• Machine stiffness is extremely low.</li> <li>• Chattering such as backlash exists.</li> </ul>
<b>Action pattern</b>	<ul style="list-style-type: none"> <li>• Motor is running continuously at low speed of 100 [r/min] or lower.</li> <li>• Acceleration/deceleration is slow (2000[r/min] per 1[s] or low).</li> <li>• Acceleration/deceleration torque is smaller than unbalanced weighted/viscous friction torque.</li> <li>• When speed condition of 100[r/min] or more and acceleration/deceleration condition of 2000[r/min] per 1[s] are not maintained for 50[ms].</li> </ul>

## How to Operate

- (1) Bring the motor to stall (Servo-OFF).
- (2) Set up Pr21 (Real-time auto-gain tuning mode setup) to 1-7. Default is 1.

Setup value	Real-time auto-gain tuning	Varying degree of load inertia in motion
0	(not in use)	-
<1>,4,7	normal mode	no change
2,5		slow change
3,6		rapid change

- When the varying degree of load inertia is large, set up 3 or 6.
- When resonance might give some effect, validate the setup of Pr23 (Setup of adaptive filter mode).

- (3) Set up Pr22 (Machine stiffness at real-time auto-gain tuning) to 0 or smaller value.
- (4) Turn to Servo-ON to run the machine normally.
- (5) Gradually increase Pr22 (Machine stiffness at real-time auto-gain tuning) when you want to obtain better response. Lower the value (0 to 3) when you experience abnormal noise or oscillation.
- (6) Write to EEPROM when you want to save the result.

Insert the console connector to CN X5 of the driver, then turn on the driver power. r 0

**Setup of parameter, Pr21**

Press **(S)**. dP\_5Pd

Press **(M)**. PR\_00

Match to the parameter No. to be set up with **(▲)** **(▼)**. (Here match to Pr21.) PR\_21

Press **(S)**. 1

Change the setup with **(▲)** **(▼)**.

Press **(S)**. PR\_21

**Setup of parameter, Pr22**

Match to Pr22 with **(▲)**. PR\_22

Press **(S)**. 4

Numeral increases with **(▲)**, and decreases with **(▼)**. (default values)

Press **(S)**.

**Writing to EEPROM**

Press **(M)**. EE\_SEt

Press **(S)**. EEP -

Bars increase as the right fig. shows by keep pressing **(▲)** (approx. 5sec). EEP --

-----

Writing starts (temporary display). StArt

Finish Finish rESEt Error

Writing completes      Writing error occurs

Return to SELECTION display after writing finishes, referring to "Structure of each mode"(P.60 and 61 of Preparation).

## Adaptive Filters

The adaptive filter is validated by setting up Pr23 (Setup of adaptive filter mode) to other than 0.

The adaptive filter automatically estimates a resonance frequency out of vibration component presented in the motor speed in motion, then removes the resonance components from the torque command by setting up the notch filter coefficient automatically, hence reduces the resonance vibration.

The adaptive filter may not operate properly under the following conditions. In these cases, use 1st notch filter (Pr1D and 1E) and 2nd notch filter (Pr28-2A) to make measures against resonance according to the manual adjusting procedures. For details of notch filters, refer to P.246, "Suppression of Machine Resonance" of Adjustment.

	Conditions which obstruct adaptive filter action
<b>Resonance point</b>	<ul style="list-style-type: none"> <li>• When resonance frequency is lower than 300[Hz].</li> <li>• While resonance peak is low or control gain is small and when no affect from these condition is given to the motor speed.</li> <li>• When multiple resonance points exist.</li> </ul>
<b>Load</b>	<ul style="list-style-type: none"> <li>• When the motor speed variation with high frequency factor is generated due to non-linear factor such as backlash.</li> </ul>
<b>Command pattern</b>	<ul style="list-style-type: none"> <li>• When acceleration/deceleration is very extreme such as more than 30000 [r/min] per 1 [s].</li> </ul>

### <Note>

Even though Pr23 is set up to other than 0, there are other cases when adaptive filter is automatically invalidated. Refer to P.235, "Invalidation of adaptive filter" of Adjustment.

## Parameters Which Are Automatically Set Up.

Following parameters are automatically adjusted.

PrNo.	Title
11	1st gain of velocity loop
12	1st time constant of velocity loop integration
13	1st filter of velocity detection
14	1st time constant of torque filter
19	2nd gain of velocity loop
1A	2nd time constant of velocity loop integration
1B	2nd filter of speed detection
1C	2nd time constant of torque filter
20	Inertia ratio
2F	Adaptive filter frequency

Also following parameters are automatically set up.

PrNo.	Title	Setup value
27	Setup of instantaneous speed observer	0
30	2nd gain setup	1
31	1st mode of control switching	0
32	1st delay time of control switching	30
33	1st level of control switching	50
34	1st hysteresis of control switching	33
36	2nd mode of control switching	0

### <Notes>

- When the real-time auto-gain tuning is valid, you cannot change parameters which are automatically adjusted.
- Pr31 becomes 10 at position or full closed control and when Pr21 (Setup of Real-Time Auto-Gain Tuning Mode) is 1-6, and becomes 0 in other cases.




## Cautions

- (1) After the start-up, you may experience abnormal noise and oscillation right after the first Servo-ON, or when you increase the setup of Pr22 (Selection of machine stiffness at real-time auto-gain tuning), until load inertia is identified (estimated) or adaptive filter is stabilized, however, these are not failures as long as they disappear immediately. If they persist over 3 reciprocating operations, take the following measures in possible order.
  - 1) Write the parameters which have given the normal operation into EEPROM.
  - 2) Lower the setup of Pr22 (Selection of machine stiffness at real-time auto-gain tuning).
  - 3) Set up both Pr21 (Setup of real-time auto-gain tuning) and Pr23 (Setup of adaptive filter mode) to 0, then set up other value than 0. (Reset of inertia estimation and adaptive action)
  - 4) Invalidate the adaptive filter by setting up Pr23 (Setup of adaptive filter mode setup) to 0, and set up notch filter manually.
- (2) When abnormal noise and oscillation occur, Pr20 (Inertia ratio) or Pr2F (Adaptive filter frequency) might have changed to extreme values. Take the same measures as the above in these cases.
- (3) Among the results of real-time auto-gain tuning, Pr20 (Inertia ratio) and Pr2F (Adaptive filter frequency) will be written to EEPROM every 30 minutes. When you turn on the power again, auto-gain tuning will be executed using the latest data as initial values.
- (4) When you validate the real-time auto-gain tuning, Pr27 (Setup of instantaneous speed observer) will be invalidated automatically.
- (5) The adaptive filter is normally invalidated at torque control, however, when you select torque control while you set up Pr02 (Control mode setup) to 4 and 5, the adaptive filter frequency before mode switching will be held.
- (6) During the trial run and frequency characteristics measurement of "PANATERM<sup>®</sup>", the load inertia estimation will be invalidated.

# Parameter Setup


## Parameters for Functional Selection

Standard default : < >

PrNo.	Title	Setup range	Function/Content																																						
00 *	Address	0 – 15 <1>	<p>In the communication with the host via RS232/485 for multi-axes application, it is necessary to identify which axis the host is communicating. Use this parameter to confirm the address of the axis in numbers.</p> <ul style="list-style-type: none"> <li>The address is determined by the setup value of rotary switch (0-F) of the front panel at power-on.</li> <li>This value becomes the axis number at serial communication.</li> <li>The setup value of this parameter has no effect to the servo action.</li> <li>You cannot change the setup of Pr00 with other means than rotary switch.</li> </ul> 																																						
01 *	LED initial status	0 – 17 <1>	<p>You can select the type of data to be displayed on the front panel LED (7 segment) at the initial status after power-on.</p> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  <p>Flashes (for approx. 2 sec) during initialization</p> <p>Setup value of Pr01</p> <p>For details of display, refer to P.51 "Setup of Parameter and Mode" of Preparation.</p> </div> <div style="flex: 1;"> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Content</th> </tr> </thead> <tbody> <tr><td>0</td><td>Positional deviation</td></tr> <tr><td>&lt;1&gt;</td><td>Motor rotational speed</td></tr> <tr><td>2</td><td>Torque output</td></tr> <tr><td>3</td><td>Control mode</td></tr> <tr><td>4</td><td>I/O signal status</td></tr> <tr><td>5</td><td>Error factor/history</td></tr> <tr><td>6</td><td>Software version</td></tr> <tr><td>7</td><td>Alarm</td></tr> <tr><td>8</td><td>Regenerative load factor</td></tr> <tr><td>9</td><td>Over-load factor</td></tr> <tr><td>10</td><td>Inertia ratio</td></tr> <tr><td>11</td><td>Sum of feedback pulses</td></tr> <tr><td>12</td><td>Sum of command pulses</td></tr> <tr><td>13</td><td>External scale deviation</td></tr> <tr><td>14</td><td>Sum of external scale feedback pulses</td></tr> <tr><td>15</td><td>Motor automatic recognizing function</td></tr> <tr><td>16</td><td>Analog input value</td></tr> <tr><td>17</td><td>Factor of "No-Motor Running"</td></tr> </tbody> </table> </div> </div>	Setup value	Content	0	Positional deviation	<1>	Motor rotational speed	2	Torque output	3	Control mode	4	I/O signal status	5	Error factor/history	6	Software version	7	Alarm	8	Regenerative load factor	9	Over-load factor	10	Inertia ratio	11	Sum of feedback pulses	12	Sum of command pulses	13	External scale deviation	14	Sum of external scale feedback pulses	15	Motor automatic recognizing function	16	Analog input value	17	Factor of "No-Motor Running"
Setup value	Content																																								
0	Positional deviation																																								
<1>	Motor rotational speed																																								
2	Torque output																																								
3	Control mode																																								
4	I/O signal status																																								
5	Error factor/history																																								
6	Software version																																								
7	Alarm																																								
8	Regenerative load factor																																								
9	Over-load factor																																								
10	Inertia ratio																																								
11	Sum of feedback pulses																																								
12	Sum of command pulses																																								
13	External scale deviation																																								
14	Sum of external scale feedback pulses																																								
15	Motor automatic recognizing function																																								
16	Analog input value																																								
17	Factor of "No-Motor Running"																																								
02 *	Setup of control mode	0 – 6 <1>	<p>You can set up the control mode to be used.</p> <table border="1"> <thead> <tr> <th rowspan="2">Setup value</th> <th colspan="2">Control mode</th> </tr> <tr> <th>1st mode</th> <th>2nd mode</th> </tr> </thead> <tbody> <tr><td>0</td><td>Position</td><td>–</td></tr> <tr><td>&lt;1&gt;</td><td>Velocity</td><td>–</td></tr> <tr><td>2</td><td>Torque</td><td>–</td></tr> <tr><td>3**1</td><td>Position</td><td>Velocity</td></tr> <tr><td>4**1</td><td>Position</td><td>Torque</td></tr> <tr><td>5**1</td><td>Velocity</td><td>Torque</td></tr> <tr><td>6</td><td>Full-closed</td><td>–</td></tr> </tbody> </table> <p>**1) When you set up the combination mode of 3, 4 or 5, you can select either the 1st or the 2nd with control mode switching input (C-MODE). When C-MODE is open, the 1st mode will be selected. When C-MODE is shorted, the 2nd mode will be selected. Don't enter commands 10ms before/after switching.</p> 	Setup value	Control mode		1st mode	2nd mode	0	Position	–	<1>	Velocity	–	2	Torque	–	3**1	Position	Velocity	4**1	Position	Torque	5**1	Velocity	Torque	6	Full-closed	–												
Setup value	Control mode																																								
	1st mode	2nd mode																																							
0	Position	–																																							
<1>	Velocity	–																																							
2	Torque	–																																							
3**1	Position	Velocity																																							
4**1	Position	Torque																																							
5**1	Velocity	Torque																																							
6	Full-closed	–																																							

# [Connection and setup of velocity control mode]

Standard default : < >

PrNo.	Title	Setup range	Function/Content																											
03	Selection of torque limit	0 – 3 <1>	<p>You can set up the torque limiting method for CCW/CW direction.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>CCW</th> <th>CW</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>X5 CCWTL : Pin-16</td> <td>X5 CWTL : Pin-18</td> </tr> <tr> <td>&lt;1&gt;</td> <td colspan="2">Pr5E is a limit value for both CCW and CW direction</td> </tr> <tr> <td>2</td> <td>Set with Pr5E</td> <td>Set with Pr5F</td> </tr> <tr> <td>3</td> <td colspan="2">When GAIN/TL-SEL input is open, set with Pr5E When GAIN/TL-SEL input is shorted, set with Pr5F</td> </tr> </tbody> </table> <p>When the setup value is 0, CCWTL and CWTL will be limited by Pr5E (1st torque limit setup). At the torque control, Pr5E becomes the limiting value for CCW/CW direction regardless of the setup of this parameter.</p>	Setup value	CCW	CW	0	X5 CCWTL : Pin-16	X5 CWTL : Pin-18	<1>	Pr5E is a limit value for both CCW and CW direction		2	Set with Pr5E	Set with Pr5F	3	When GAIN/TL-SEL input is open, set with Pr5E When GAIN/TL-SEL input is shorted, set with Pr5F													
Setup value	CCW	CW																												
0	X5 CCWTL : Pin-16	X5 CWTL : Pin-18																												
<1>	Pr5E is a limit value for both CCW and CW direction																													
2	Set with Pr5E	Set with Pr5F																												
3	When GAIN/TL-SEL input is open, set with Pr5E When GAIN/TL-SEL input is shorted, set with Pr5F																													
04 *	Setup of over-travel inhibit input	0 – 2 <1>	<p>In linear drive application, you can use this over-travel inhibiting function to inhibit the motor to run to the direction specified by limit switches which are installed at both ends of the axis, so that you can prevent the work load from damaging the machine due to the over-travel. With this input, you can set up the action of over-travel inhibit input.</p>  <table border="1"> <thead> <tr> <th>Setup value</th> <th>CCWL/CWL input</th> <th>Input</th> <th>Connection to COM-</th> <th>Action</th> </tr> </thead> <tbody> <tr> <td rowspan="4">0</td> <td rowspan="4">Valid</td> <td rowspan="2">CCWL (CN X5,Pin-9)</td> <td>Close</td> <td>Normal status while CCW-side limit switch is not activated.</td> </tr> <tr> <td>Open</td> <td>Inhibits CCW direction, permits CW direction.</td> </tr> <tr> <td rowspan="2">CWL (CN X5,Pin-9)</td> <td>Close</td> <td>Normal status while CW-side limit switch is not activated.</td> </tr> <tr> <td>Open</td> <td>Inhibits CW direction, CCW direction permitted.</td> </tr> <tr> <td>&lt;1&gt;</td> <td>Invalid</td> <td colspan="3">Both CCWL and CWL inputs will be ignored, and over-travel inhibit function will be invalidated.</td> </tr> <tr> <td>2</td> <td>Valid</td> <td colspan="3">Err38 (Over-travel inhibit input protection) is triggered when either one of the connection of CW or CCW inhibi</td> </tr> </tbody> </table> <p><b>&lt;Cautions&gt;</b></p> <ol style="list-style-type: none"> <li>When Pr04 is set to 0 and over-travel inhibit input is entered, the motor decelerates and stops according to the preset sequence with Pr66 (Sequence at over-travel inhibition). For details, refer to the explanation of Pr66.</li> <li>When both of CCWL and CWL inputs are opened while Pr04 is set to 0, the driver trips with Err38 (Overtravel inhibit input error) judging that this is an error.</li> <li>When you turn off the limit switch on upper side of the work at vertical axis application, the work may repeat up/down movement because of the loosing of upward torque. In this case, set up Pr66 to 2, or limit with the host controller instead of using this function.</li> </ol>	Setup value	CCWL/CWL input	Input	Connection to COM-	Action	0	Valid	CCWL (CN X5,Pin-9)	Close	Normal status while CCW-side limit switch is not activated.	Open	Inhibits CCW direction, permits CW direction.	CWL (CN X5,Pin-9)	Close	Normal status while CW-side limit switch is not activated.	Open	Inhibits CW direction, CCW direction permitted.	<1>	Invalid	Both CCWL and CWL inputs will be ignored, and over-travel inhibit function will be invalidated.			2	Valid	Err38 (Over-travel inhibit input protection) is triggered when either one of the connection of CW or CCW inhibi		
Setup value	CCWL/CWL input	Input	Connection to COM-	Action																										
0	Valid	CCWL (CN X5,Pin-9)	Close	Normal status while CCW-side limit switch is not activated.																										
			Open	Inhibits CCW direction, permits CW direction.																										
		CWL (CN X5,Pin-9)	Close	Normal status while CW-side limit switch is not activated.																										
			Open	Inhibits CW direction, CCW direction permitted.																										
<1>	Invalid	Both CCWL and CWL inputs will be ignored, and over-travel inhibit function will be invalidated.																												
2	Valid	Err38 (Over-travel inhibit input protection) is triggered when either one of the connection of CW or CCW inhibi																												

## <Notes>

- For parameters which No. have a suffix of "\*", changed contents will be validated when you turn on the control power.

# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Function/Content																																																																																
05	Speed setup, Internal/External switching	0 – 3 <0>	<p>This driver is equipped with internal speed setup function so that you can control the speed with contact inputs only.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Speed setup method</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td>External speed command (SPR:CN X5, Pin-14)</td> </tr> <tr> <td>1</td> <td>Internal speed command 1st-4th speed (Pr53-Pr56)</td> </tr> <tr> <td>2</td> <td>Internal speed command 1st-3rd speed (Pr53-Pr55), External speed command (SPR)</td> </tr> <tr> <td>3</td> <td>Internal speed command 1st-8th speed (Pr53-Pr56, Pr74-Pr77)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li>You can select a speed command at velocity control.</li> <li>When the setup value is 1 or 2, switch 4 kinds of internal speed command with 2 kinds of contact input. <ul style="list-style-type: none"> <li>(1) INH (CN X5, Pin-33) : Selection 1 input of internal command speed</li> <li>(2) INH (CN X5, Pin-30) : Selection 2 input of internal command speed</li> </ul> </li> <li>When the setup value is 3, switch 8 kinds of internal speed command with 3 kinds of contact input. <ul style="list-style-type: none"> <li>(1) INH (CN X5, Pin-33) : Selection 1 input of internal command speed</li> <li>(2) INH (CN X5, Pin-30) : Selection 2 input of internal command speed</li> <li>(3) INH (CN X5, Pin-28) : Selection 3 input of internal command speed</li> </ul> </li> </ul> <p>DIV input is ignored.</p> <p><b>• Selection of internal speed</b></p> <table border="1"> <thead> <tr> <th colspan="3">Connector Pin No. of X5</th> <th colspan="4">Pr05, Internal/external switching of speed setup</th> </tr> <tr> <th>Pin-33 INTSPD1(INH)</th> <th>Pin-30 INTSPD2(CL)</th> <th>Pin-28 INTSPD3(DIV)</th> <th>0</th> <th>1</th> <th>2</th> <th>3</th> </tr> </thead> <tbody> <tr> <td>open</td> <td>open</td> <td>open</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>1st speed of speed setup (Pr53)</td> <td>1st speed of speed setup (Pr53)</td> <td>1st speed of speed setup (Pr53)</td> </tr> <tr> <td>short</td> <td>open</td> <td>open</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>2nd speed of speed setup (Pr54)</td> <td>2nd speed of speed setup (Pr54)</td> <td>2nd speed of speed setup (Pr54)</td> </tr> <tr> <td>open</td> <td>short</td> <td>open</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>3rd speed of speed setup (Pr55)</td> <td>3rd speed of speed setup (Pr55)</td> <td>3rd speed of speed setup (Pr55)</td> </tr> <tr> <td>short</td> <td>short</td> <td>open</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>4th speed of speed setup (Pr56)</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>4th speed of speed setup (Pr56)</td> </tr> <tr> <td>open</td> <td>open</td> <td>short</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>1st speed of speed setup (Pr53)</td> <td>1st speed of speed setup (Pr53)</td> <td>5th speed of speed setup (Pr74)</td> </tr> <tr> <td>short</td> <td>open</td> <td>short</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>2nd speed of speed setup (Pr54)</td> <td>2nd speed of speed setup (Pr54)</td> <td>6th speed of speed setup (Pr75)</td> </tr> <tr> <td>open</td> <td>short</td> <td>short</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>3rd speed of speed setup (Pr55)</td> <td>3rd speed of speed setup (Pr55)</td> <td>7th speed of speed setup (Pr76)</td> </tr> <tr> <td>short</td> <td>short</td> <td>short</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>4th speed of speed setup (Pr56)</td> <td>Analog speed command (CN X5, Pin-14)</td> <td>8th speed of speed setup (Pr77)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li>Example of 4-speed run with internal speed command. In addition to CL/INH inputs, use the speed zero clamp input (ZEROSPD) and Servo-ON input (SRV-ON) to control the motor stop and start.</li> </ul> <div style="display: flex; align-items: flex-start;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <p><b>&lt;Caution&gt;</b> You can individually set up acceleration time, deceleration time, and sigmoid acceleration/ deceleration time with parameter. Refer to Pr58 : Acceleration time setup Pr59 : Deceleration time setup Pr5A : Sigmoid acceleration/ deceleration time setup in this Chapter.</p> </div> </div>	Setup value	Speed setup method	<0>	External speed command (SPR:CN X5, Pin-14)	1	Internal speed command 1st-4th speed (Pr53-Pr56)	2	Internal speed command 1st-3rd speed (Pr53-Pr55), External speed command (SPR)	3	Internal speed command 1st-8th speed (Pr53-Pr56, Pr74-Pr77)	Connector Pin No. of X5			Pr05, Internal/external switching of speed setup				Pin-33 INTSPD1(INH)	Pin-30 INTSPD2(CL)	Pin-28 INTSPD3(DIV)	0	1	2	3	open	open	open	Analog speed command (CN X5, Pin-14)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)	short	open	open	Analog speed command (CN X5, Pin-14)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)	open	short	open	Analog speed command (CN X5, Pin-14)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)	short	short	open	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)	open	open	short	Analog speed command (CN X5, Pin-14)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)	5th speed of speed setup (Pr74)	short	open	short	Analog speed command (CN X5, Pin-14)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)	6th speed of speed setup (Pr75)	open	short	short	Analog speed command (CN X5, Pin-14)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)	7th speed of speed setup (Pr76)	short	short	short	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)	Analog speed command (CN X5, Pin-14)	8th speed of speed setup (Pr77)
Setup value	Speed setup method																																																																																		
<0>	External speed command (SPR:CN X5, Pin-14)																																																																																		
1	Internal speed command 1st-4th speed (Pr53-Pr56)																																																																																		
2	Internal speed command 1st-3rd speed (Pr53-Pr55), External speed command (SPR)																																																																																		
3	Internal speed command 1st-8th speed (Pr53-Pr56, Pr74-Pr77)																																																																																		
Connector Pin No. of X5			Pr05, Internal/external switching of speed setup																																																																																
Pin-33 INTSPD1(INH)	Pin-30 INTSPD2(CL)	Pin-28 INTSPD3(DIV)	0	1	2	3																																																																													
open	open	open	Analog speed command (CN X5, Pin-14)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)																																																																													
short	open	open	Analog speed command (CN X5, Pin-14)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)																																																																													
open	short	open	Analog speed command (CN X5, Pin-14)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)																																																																													
short	short	open	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)																																																																													
open	open	short	Analog speed command (CN X5, Pin-14)	1st speed of speed setup (Pr53)	1st speed of speed setup (Pr53)	5th speed of speed setup (Pr74)																																																																													
short	open	short	Analog speed command (CN X5, Pin-14)	2nd speed of speed setup (Pr54)	2nd speed of speed setup (Pr54)	6th speed of speed setup (Pr75)																																																																													
open	short	short	Analog speed command (CN X5, Pin-14)	3rd speed of speed setup (Pr55)	3rd speed of speed setup (Pr55)	7th speed of speed setup (Pr76)																																																																													
short	short	short	Analog speed command (CN X5, Pin-14)	4th speed of speed setup (Pr56)	Analog speed command (CN X5, Pin-14)	8th speed of speed setup (Pr77)																																																																													
06	Selection of ZEROSPD input	0 – 2 <0>	<p>You can set up the function of the speed zero clamp input (ZEROSPD : CN X5, Pin-26)</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Function of ZEROSPD (Pin-26)</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td>ZEROSPD input is ignored and the driver judge that it is not in speed zero clamp status.</td> </tr> <tr> <td>1</td> <td>ZEROSPD input becomes valid. Speed command is taken as 0 by opening the connection to COM-.</td> </tr> <tr> <td>2</td> <td>Becomes speed command sign. You can set command direction to CCW by opening the connection to COM-, and CW by closing.</td> </tr> </tbody> </table>	Setup value	Function of ZEROSPD (Pin-26)	<0>	ZEROSPD input is ignored and the driver judge that it is not in speed zero clamp status.	1	ZEROSPD input becomes valid. Speed command is taken as 0 by opening the connection to COM-.	2	Becomes speed command sign. You can set command direction to CCW by opening the connection to COM-, and CW by closing.																																																																								
Setup value	Function of ZEROSPD (Pin-26)																																																																																		
<0>	ZEROSPD input is ignored and the driver judge that it is not in speed zero clamp status.																																																																																		
1	ZEROSPD input becomes valid. Speed command is taken as 0 by opening the connection to COM-.																																																																																		
2	Becomes speed command sign. You can set command direction to CCW by opening the connection to COM-, and CW by closing.																																																																																		

# [Connection and setup of velocity control mode]

Standard default : < >

PrNo.	Title	Setup range	Function/Content		
07	Selection of speed monitor (SP)	0 – 9 <3>	You can set up the content of analog speed monitor signal output (SP : CN X5, Pin43) and the relation between the output voltage level and the speed.		
			<b>Setup value</b>	<b>Signal of SP</b>	<b>Relation between the output voltage level and the speed</b>
			0	Motor actual speed	6V / 47 r/min
			1		6V / 188 r/min
			2		6V / 750 r/min
			<3>		6V / 3000 r/min
			4		1.5V / 3000 r/min
			5	Command speed	6V / 47 r/min
			6		6V / 188 r/min
			7		6V / 750 r/min
			8		6V / 3000 r/min
9	1.5V / 3000 r/min				
08	Selection of torque monitor (IM)	0 – 12 <0>	You can set up the content of the analog torque monitor of the signal output (IM : CN X5, Pin-42), and the relation between the output voltage level and torque or deviation pulse counts.		
			<b>Setup value</b>	<b>Signal of IM</b>	<b>Relation between the output voltage level and torque or deviation pulse counts</b>
			<0>	Torque command	3V/rated (100%) torque
			1	Position deviation	3V / 31Pulse
			2		3V / 125Pulse
			3		3V / 500Pulse
			4		3V / 2000Pulse
			5		3V / 8000Pulse
			6	Full-closed deviation	3V / 31Pulse
			7		3V / 125Pulse
			8		3V / 500Pulse
			9		3V / 2000Pulse
			10		3V / 8000Pulse
11	Torque command	3V / 200% torque			
12	Torque command	3V / 400% torque			
09	Selection of TLC output	0 – 8 <0>	You can assign the function of the torque in-limit output (TLC : CN X5 Pin-40).		
			<b>Setup value</b>	<b>Function</b>	<b>Note</b>
			<0>	Torque in-limit output	For details of function of each output of the left, refer to the table of P135, "Selection of TCL and ZSP outputs".
			1	Zero speed detection output	
			2	Alarm output of either one of Over-regeneration /Over-load/Absolute battery/Fan lock/External scale	
			3	Over-regeneration alarm trigger output	
			4	Overload alarm output	
			5	Absolute battery alarm output	
			6	Fan lock alarm output	
7	External scale alarm output				
8	In-speed (Speed coincidence) output				
0A	Selection of ZSP output	0 – 8 <1>	You can assign the function of the zero speed detection output (ZSP: CN X5 Pin-12).		
			<b>Setup value</b>	<b>Function</b>	<b>Note</b>
			0	Torque in-limit output	For details of function of each output of the left, refer to the table of P.135, "Selection of TCL and ZSP outputs".
			<1>	Zero speed detection output	
			2	Alarm output of either one of Over-regeneration /Over-load/Absolute battery/Fan lock/External scale	
			3	Over-regeneration alarm trigger output	
			4	Overload alarm output	
			5	Absolute battery alarm output	
			6	Fan lock alarm output	
7	External scale alarm output				
8	In-speed (Speed coincidence) output				

# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Function/Content																
0B *	Setup of absolute encoder	0 – 2 <1>	<p>You can set up the using method of 17-bit absolute encoder.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Use as an absolute encoder.</td> </tr> <tr> <td>&lt;1&gt;</td> <td>Use as an incremental encoder.</td> </tr> <tr> <td>2</td> <td>Use as an absolute encoder, but ignore the multi-turn counter over.</td> </tr> </tbody> </table> <p><b>&lt;Caution&gt;</b> This parameter will be invalidated when 5-wire, 2500P/r incremental encoder is used.</p>	Setup value	Content	0	Use as an absolute encoder.	<1>	Use as an incremental encoder.	2	Use as an absolute encoder, but ignore the multi-turn counter over.								
Setup value	Content																		
0	Use as an absolute encoder.																		
<1>	Use as an incremental encoder.																		
2	Use as an absolute encoder, but ignore the multi-turn counter over.																		
0C *	Baud rate setup of RS232 communication	0 – 5 <2>	<p>You can set up the communication speed of RS232. • Error of baud rate is <math>\pm 0.5\%</math>.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Baud rate</th> <th>Setup value</th> <th>Baud rate</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>2400bps</td> <td>3</td> <td>19200bps</td> </tr> <tr> <td>1</td> <td>4800bps</td> <td>4</td> <td>38400bps</td> </tr> <tr> <td>&lt;2&gt;</td> <td>9600bps</td> <td>5</td> <td>57600bps</td> </tr> </tbody> </table>	Setup value	Baud rate	Setup value	Baud rate	0	2400bps	3	19200bps	1	4800bps	4	38400bps	<2>	9600bps	5	57600bps
Setup value	Baud rate	Setup value	Baud rate																
0	2400bps	3	19200bps																
1	4800bps	4	38400bps																
<2>	9600bps	5	57600bps																
0D *	Baud rate setup of RS485 communication	0 – 5 <2>	<p>You can set up the communication speed of RS485. • Error of baud rate is <math>\pm 0.5\%</math>.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Baud rate</th> <th>Setup value</th> <th>Baud rate</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>2400bps</td> <td>3</td> <td>19200bps</td> </tr> <tr> <td>1</td> <td>4800bps</td> <td>4</td> <td>38400bps</td> </tr> <tr> <td>&lt;2&gt;</td> <td>9600bps</td> <td>5</td> <td>57600bps</td> </tr> </tbody> </table>	Setup value	Baud rate	Setup value	Baud rate	0	2400bps	3	19200bps	1	4800bps	4	38400bps	<2>	9600bps	5	57600bps
Setup value	Baud rate	Setup value	Baud rate																
0	2400bps	3	19200bps																
1	4800bps	4	38400bps																
<2>	9600bps	5	57600bps																
0E *	Setup of front panel lock	0 – 1 <0>	<p>You can limit the operation of the front panel to the monitor mode only. You can prevent such a misoperation as unexpected parameter change.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Content</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td>Valid to all</td> </tr> <tr> <td>1</td> <td>Monitor mode only</td> </tr> </tbody> </table> <p><b>&lt;Note&gt;</b> You can still change parameters via communication even though this setup is 1. To return this parameter to 0, use the console or the "PANATERM®".</p>	Setup value	Content	<0>	Valid to all	1	Monitor mode only										
Setup value	Content																		
<0>	Valid to all																		
1	Monitor mode only																		

## Parameters for Adjustment of Time Constants of Gains and Filters

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content
11	1st gain of velocity loop	1 – 3500 A-C-frame:<35>* D-F-frame:<18>*	Hz	<p>You can determine the response of the velocity loop. In order to increase the response of overall servo system by setting high position loop gain, you need higher setup of this velocity loop gain as well. However, too high setup may cause oscillation.</p> <p><b>&lt;Caution&gt;</b> When the inertia ratio of Pr20 is set correctly, the setup unit of Pr11 becomes (Hz).</p>
12	1st time constant of velocity loop integration	1 – 1000 A-C-frame:<16>* D-F-frame:<31>*	ms	<p>You can set up the integration time constant of velocity loop. Smaller the setup, faster you can dog-in deviation at stall to 0. The integration will be maintained by setting to "999". The integration effect will be lost by setting to "1000".</p>
13	1st filter of speed detection	0 – 5 <0>*	–	<p>You can set up the time constant of the low pass filter (LPF) after the speed detection, in 6 steps. Higher the setup, larger the time constant you can obtain so that you can decrease the motor noise, however, response becomes slow. Use with a default value of 0 in normal operation.</p>
14	1st time constant of torque filter	0 – 2500 A-C-frame:<65>* D-F-frame:<126>*	0.01ms	<p>You can set up the time constant of the 1st delay filter inserted in the torque command portion. You might expect suppression of oscillation caused by distortion resonance.</p>

# [Connection and setup of velocity control mode]

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content
19	2nd gain of velocity loop	1 – 3500 A-C-frame:<35>* D-F-frame:<18>*	Hz	Position loop, velocity loop, speed detection filter and torque command filter have their 2 pairs of gain or time constant (1st and 2nd). For details of switching the 1st and the 2nd gain or the time constant, refer to P.226, "Adjustment". The function and the content of each parameter is as same as that of the 1st gain and time constant.
1A	2nd time constant of velocity loop integration	1 – 1000 <1000>*	ms	
1B	1st filter of speed detection	0 – 5 <0>*	–	
1C	2nd filter of velocity detection	0 – 2500 A-C-frame:<65>* D-F-frame:<126>*	0.01ms	
1D	2nd time constant of torque filter	100 – 1500 <1500>	Hz	You can set up the frequency of the 1st resonance suppressing notch filter. The notch filter function will be invalidated by setting up this parameter to "1500".
1E	1st notch frequency	0 – 4 <2>	–	You can set up the notch filter width of the 1st resonance suppressing filter in 5 steps. Higher the setup, larger the notch width you can obtain. Use with default setup in normal operation.

## Parameters for Auto-Gain Tuning

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content													
20	Inertia ratio	0 – 10000 <250>*	%	<p>You can set up the ratio of the load inertia against the rotor (of the motor) inertia.</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 5px auto;"> <math display="block">Pr20 = (\text{load inertia} / \text{rotor inertia}) \times 100 [\%]</math> </div> <p>When you execute the normal auto-gain tuning, the load inertial will be automatically estimated after the preset action, and this result will be reflected in this parameter. The inertia ratio will be estimated at all time while the real-time auto-gain tuning is valid, and its result will be saved to EEPROM every 30 min.</p> <p><b>&lt;Caution&gt;</b> If the inertia ratio is correctly set, the setup unit of Pr11 and Pr19 becomes (Hz). When the inertia ratio of Pr20 is larger than the actual, the setup unit of the velocity loop gain becomes larger, and when the inertia ratio of Pr is smaller than the actual, the setup unit of the velocity loop gain becomes smaller.</p>													
21	Setup of real-time auto-gain tuning	0 – 7 <1>	–	<p>You can set up the action mode of the real-time auto-gain tuning. With higher setup such as 3, the driver respond quickly to the change of the inertia during operation, however it might cause an unstable operation. Use 1 for normal operation.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Setup value</th> <th>Real-time auto-gain tuning</th> <th>Varying degree of load inertia in motion</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Invalid</td> <td>–</td> </tr> <tr> <td>&lt;1&gt;, 4, 7</td> <td rowspan="3" style="text-align: center;">Normal mode</td> <td>Little change</td> </tr> <tr> <td>2, 5</td> <td>Gradual change</td> </tr> <tr> <td>3, 6</td> <td>Rapid change</td> </tr> </tbody> </table>	Setup value	Real-time auto-gain tuning	Varying degree of load inertia in motion	0	Invalid	–	<1>, 4, 7	Normal mode	Little change	2, 5	Gradual change	3, 6	Rapid change
Setup value	Real-time auto-gain tuning	Varying degree of load inertia in motion															
0	Invalid	–															
<1>, 4, 7	Normal mode	Little change															
2, 5		Gradual change															
3, 6		Rapid change															

### <Notes>

- For parameters which No. have a suffix of "\*", changed contents will be validated when you turn on the control power.
- Parameters which default values have a suffix of "\*" will be automatically set up during real time auto-gain tuning. When you change manually, invalidate the real-time auto-gain tuning first then set, referring to P.239, "Release of Automatic Gain Adjusting Function" of Adjustment.

# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content																					
22	Selection of machine stiffness at real-time auto-gain tuning	0 – 15 A–C-frame: <4> D–F-frame: <1>	–	<p>You can set up the machine stiffness in 16 steps while the real-time auto-gain tuning is valid.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td style="text-align: center;">low ← machine stiffness → high</td> </tr> <tr> <td></td> <td style="text-align: center;">low ← servo gain → high</td> </tr> <tr> <td style="text-align: center;">Pr22</td> <td style="text-align: center;">0, 1-----14, 15</td> </tr> <tr> <td></td> <td style="text-align: center;">low ← response → high</td> </tr> </table> <p><b>&lt;Caution&gt;</b> When you change the setup value rapidly, the gain changes rapidly as well, and this may give impact to the machine. Increase the setup gradually watching the movement of the machine.</p>		low ← machine stiffness → high		low ← servo gain → high	Pr22	0, 1-----14, 15		low ← response → high													
	low ← machine stiffness → high																								
	low ← servo gain → high																								
Pr22	0, 1-----14, 15																								
	low ← response → high																								
23	Setup of adaptive filter mode	0 – 2 <1>	–	<p>You can set up the action of the adaptive filter.</p> <p>0 : Invalid 1 : Valid 2 : Hold (holds the adaptive filter frequency when this setup is changed to 2.)</p> <p><b>&lt;Caution&gt;</b> When you set up the adaptive filter to invalid, the adaptive filter frequency of Pr2F will be reset to 0. The adaptive filter is always invalid at the torque control mode.</p>																					
25	Setup of an action at normal mode auto-gain tuning	0 – 7 <0>	–	<p>You can set up the action pattern at the normal mode auto-gain tuning.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Setup value</th> <th>Number of revolution</th> <th>Rotational direction</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td rowspan="4" style="text-align: center;">2 [revolution]</td> <td style="text-align: center;">CCW → CW</td> </tr> <tr> <td>1</td> <td style="text-align: center;">CW → CCW</td> </tr> <tr> <td>2</td> <td style="text-align: center;">CCW → CCW</td> </tr> <tr> <td>3</td> <td style="text-align: center;">CW → CW</td> </tr> <tr> <td>4</td> <td rowspan="4" style="text-align: center;">1 [revolution]</td> <td style="text-align: center;">CCW → CW</td> </tr> <tr> <td>5</td> <td style="text-align: center;">CW → CCW</td> </tr> <tr> <td>6</td> <td style="text-align: center;">CCW → CCW</td> </tr> <tr> <td>7</td> <td style="text-align: center;">CW → CW</td> </tr> </tbody> </table> <p>e.g.) When the setup is 0, the motor turns 2 revolutions to CCW and 2 revolutions to CW.</p>	Setup value	Number of revolution	Rotational direction	<0>	2 [revolution]	CCW → CW	1	CW → CCW	2	CCW → CCW	3	CW → CW	4	1 [revolution]	CCW → CW	5	CW → CCW	6	CCW → CCW	7	CW → CW
Setup value	Number of revolution	Rotational direction																							
<0>	2 [revolution]	CCW → CW																							
1		CW → CCW																							
2		CCW → CCW																							
3		CW → CW																							
4	1 [revolution]	CCW → CW																							
5		CW → CCW																							
6		CCW → CCW																							
7		CW → CW																							
27	Setup of instantaneous speed observer	0 – 1 <0>*	–	<p>With a high stiffness machine, you can achieve both high response and reduction of vibration at stall, by using this instantaneous speed observer.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Setup value</th> <th>Instantaneous speed observer setup</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;*</td> <td style="text-align: center;">Invalid</td> </tr> <tr> <td>1</td> <td style="text-align: center;">Valid</td> </tr> </tbody> </table> <p style="margin-left: 20px;">You need to set up the inertia ratio of Pr20 correctly to use this function. If you set up Pr21, real-time auto-gain tuning mode setup, to other than 0 (valid), Pr27 becomes 0 (invalid)</p>	Setup value	Instantaneous speed observer setup	<0>*	Invalid	1	Valid															
Setup value	Instantaneous speed observer setup																								
<0>*	Invalid																								
1	Valid																								
28	2nd notch frequency	100 – 1500 <1500>	Hz	<p>You can set up the 2nd notch width of the resonance suppressing filter in 5 steps. The notch filter function is invalidated by setting up this parameter to "1500".</p>																					
29	Selection of 2nd notch width	0 – 4 <2>	–	<p>You can set up the notch width of 2nd resonance suppressing filter in 5 steps. Higher the setup, larger the notch width you can obtain. Use with default setup in normal operation.</p>																					
2A	Selection of 2nd notch depth	0 – 99 <0>	–	<p>You can set up the 2nd notch depth of the resonance suppressing filter. Higher the setup, shallower the notch depth and smaller the phase delay you can obtain.</p>																					

## <Notes>

- Parameters which default values have a suffix of "\*" will be automatically set up during real time auto-gain tuning. When you change manually, invalidate the real-time auto-gain tuning first then set, referring to P.239, "Release of Automatic Gain Adjusting Function" of Adjustment.

# [Connection and setup of velocity control mode]

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content
2F	Adaptive filter frequency	0 – 64 <0>	–	<p>Displays the table No. corresponding to the adaptive filter frequency. (Refer to P.234 of Adjustment.) This parameter will be automatically set and cannot be changed while the adaptive filter is valid. (when Pr23 (Setuo of adaptive filter mode) is other than 0.)</p> <p>0 – 4 Filter is invalid. 5 – 48 Filter is valid. 49 – 64 Filter validity changes according to Pr22.</p> <p>This parameter will be saved to EEPROM every 30 minutes while the adaptive filter is valid, and when the adaptive filter is valid at the next power-on, the adaptive action starts taking the saved data in EEPROM as an initial value.</p> <p><b>&lt;Caution&gt;</b> When you need to clear this parameter to reset the adaptive action while the action is not normal, invalidate the adaptive filter (Pr23, "Setup of adaptive filter mode" to 0) once, then validate again. Refer to P.239, "Release of Automatic Gain Adjusting Function" of Adjustment as well.</p>

## Parameters for Adjustment (2nd Gain Switching Function)



Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content														
30	Setup of 2nd gain	0 – 1 <1>*	–	<p>You can select the PI/P action switching of the velocity control or 1st/2nd gain switching.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Gain selection/switching</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1st gain (PI/P switching enabled) *1</td> </tr> <tr> <td>&lt;1&gt;*</td> <td>1st/2nd gain switching enabled *2</td> </tr> </tbody> </table> <p>*1 Switch the PI/P action with the gain switching input (GAIN CN X5, Pin-27). PI is fixed when Pr03 (Torque limit selection) is 3.</p> <table border="1"> <thead> <tr> <th>GAIN input</th> <th>Action of velocity loop</th> </tr> </thead> <tbody> <tr> <td>Open with COM–</td> <td>PI action</td> </tr> <tr> <td>Connect to COM–</td> <td>P action</td> </tr> </tbody> </table> <p>*2 For switching condition of the 1st and the 2nd, refer to P.243, "Gain Switching Function" of Adjustment.</p>	Setup value	Gain selection/switching	0	1st gain (PI/P switching enabled) *1	<1>*	1st/2nd gain switching enabled *2	GAIN input	Action of velocity loop	Open with COM–	PI action	Connect to COM–	P action		
Setup value	Gain selection/switching																	
0	1st gain (PI/P switching enabled) *1																	
<1>*	1st/2nd gain switching enabled *2																	
GAIN input	Action of velocity loop																	
Open with COM–	PI action																	
Connect to COM–	P action																	
31	1st mode of control switching	0 – 10 <0>*	–	<p>You can select the switching condition of 1st gain and 2nd gain while Pr30 is set to 1.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Gain switching condition</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;*, 6 – 10</td> <td>Fixed to the 1st gain.</td> </tr> <tr> <td>1</td> <td>Fixed to 2nd gain.</td> </tr> <tr> <td>2 *1</td> <td>2nd gain selection when the gain switching input is turned on. (Pr30 setup must be 1.)</td> </tr> <tr> <td>3 *2</td> <td>2nd gain selection when the toque command variation is larger than the setups of Pr33 (1st level of control switching) and Pr34 (1st hysteresis of control switching).</td> </tr> <tr> <td>4 *2</td> <td>Fixed to the 1st gain.</td> </tr> <tr> <td>5 *2</td> <td>2nd gain selection when the command speed is larger than the setups of Pr33 (1st level of control switching) and Pr34 (1st hysteresis at control switching).</td> </tr> </tbody> </table> <p>*1 Fixed to the 1st gain regardless of GAIN input, when Pr31 is set to 2 and Pr03 (Torque limit selection) is set to 3. *2 For the switching level and the timing, refer to P.243, "Gain Switching Function" of Adjustment.</p>	Setup value	Gain switching condition	<0>*, 6 – 10	Fixed to the 1st gain.	1	Fixed to 2nd gain.	2 *1	2nd gain selection when the gain switching input is turned on. (Pr30 setup must be 1.)	3 *2	2nd gain selection when the toque command variation is larger than the setups of Pr33 (1st level of control switching) and Pr34 (1st hysteresis of control switching).	4 *2	Fixed to the 1st gain.	5 *2	2nd gain selection when the command speed is larger than the setups of Pr33 (1st level of control switching) and Pr34 (1st hysteresis at control switching).
Setup value	Gain switching condition																	
<0>*, 6 – 10	Fixed to the 1st gain.																	
1	Fixed to 2nd gain.																	
2 *1	2nd gain selection when the gain switching input is turned on. (Pr30 setup must be 1.)																	
3 *2	2nd gain selection when the toque command variation is larger than the setups of Pr33 (1st level of control switching) and Pr34 (1st hysteresis of control switching).																	
4 *2	Fixed to the 1st gain.																	
5 *2	2nd gain selection when the command speed is larger than the setups of Pr33 (1st level of control switching) and Pr34 (1st hysteresis at control switching).																	

# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content										
32	1st delay time of control switching	0 – 10000 <30>* x 166μs	x 166μs	You can set up the delay time when returning from the 2nd to the 1st gain, while Pr31 is set to 3 or 5-10.										
33	1st level of control switching	0 – 20000 <50>* –	–	You can set up the switching (judging) level of the 1st and the 2nd gains, while Pr31 is set to 3, 5, 6, 9 and 10. Unit varies depending on the setup of Pr31 (1st mode of control switching)										
34	1st hysteresis of control switching	0 – 20000 <33>* –	–	You can set up hysteresis width to be implemented above/below the judging level which is set up with Pr33. Unit varies depending on the setup of Pr31 (1st control switching mode). Definitions of Pr32 (Delay), Pr33 (Level) and Pr34 (Hysteresis) are explained in the fig. below. <b>&lt;Caution&gt;</b> The setup of Pr33 (Level) and Pr34 (Hysteresis) are valid as absolute values (positive/negative).										
36	2nd mode of control switching	0 – 5 <0>* –	–	You can select the switching condition of the 1st and 2nd gain while Pr30 is set to 1 and when the 2nd control mode is velocity control.										
				<table border="1"> <thead> <tr> <th>Setup value</th> <th>Gain switching condition</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;*</td> <td>Fixed to the 1st gain</td> </tr> <tr> <td>1</td> <td>Fixed to the 2nd gain</td> </tr> <tr> <td>2 *1</td> <td>2nd gain selection when gain switching input is turned on (GAIN : CN X5, Pin-27) (Pr30 setup must be 1.)</td> </tr> <tr> <td>3 *2</td> <td>2nd gain selection when the torque command variation is larger.</td> </tr> <tr> <td>4 *2</td> <td>2nd gain selection when the speed command variation (acceleration) is larger.</td> </tr> <tr> <td>5 *2</td> <td>2nd gain selection when the command speed is larger.</td> </tr> </tbody> </table> <p>*1 Fixed to the 1st gain regardless of the GAIN input, when Pr31 is set to 2 and Pr03 (Torque limit selection) is set to 3. *2 For the switching level and timing, refer to P.244, "Setup of Gain Switching Condition" of Adjustment.</p>	Setup value	Gain switching condition	<0>*	Fixed to the 1st gain	1	Fixed to the 2nd gain	2 *1	2nd gain selection when gain switching input is turned on (GAIN : CN X5, Pin-27) (Pr30 setup must be 1.)	3 *2	2nd gain selection when the torque command variation is larger.
Setup value	Gain switching condition													
<0>*	Fixed to the 1st gain													
1	Fixed to the 2nd gain													
2 *1	2nd gain selection when gain switching input is turned on (GAIN : CN X5, Pin-27) (Pr30 setup must be 1.)													
3 *2	2nd gain selection when the torque command variation is larger.													
4 *2	2nd gain selection when the speed command variation (acceleration) is larger.													
5 *2	2nd gain selection when the command speed is larger.													
37	2nd delay time of control switching	0 – 10000 <0> x 166μs	x 166μs	You can set up the delay time when returning from 2nd to 1st gain, while Pr36 is set to 3 to 5.										
38	2nd level of control switching	0 – 20000 <0> –	–	You can set up the switching (judging) level of the 1st and the 2nd gains, while Pr36 is set to 3-5 Unit varies depending on the setup of Pr36 (2nd mode of control switching).										
39	2nd hysteresis of control switching	0 – 20000 <0> –	–	You can set up the hysteresis width to be implemented above/below the judging level which is set up with Pr38. Unit varies depending on the setup of Pr36 (2nd mode of control switching). Definition of Pr37 (Delay), Pr38 (Level) and Pr39 (Hysteresis) are explained in the fig. below. <b>&lt;Caution&gt;</b> Setup of Pr38 (Level) and Pr39 (Hysteresis) are valid as absolute value (positive/negative).										
3D	JOG speed setup	0 – 500 <300> r/min	r/min	You can setup the JOG speed. Refer to P.75, "Trial Run" of Preparation.										



## <Notes>

- Parameters which default values have a suffix of "\*" will be automatically set up during real time auto-gain tuning. When you change manually, invalidate the real-time auto-gain tuning first then set, referring to P.239, "Release of Automatic Gain Adjusting Function" of Adjustment.

Parameters for Position Control

Standard default : < >

PrNo.	Title	Setup range	Function/Content
44 *	Numerator of pulse output division	1 – 32767 <2500>	<p>You can set up the pulse counts to be fed out from the pulse output (X5 0A+ : Pin-21, 0A- : Pin-22, 0B+ : Pin-48, 0B- : Pin-49).</p> <div style="border: 1px solid black; padding: 5px;"> <p>• <b>Pr45=&lt;0&gt; (Default)</b>                      You can set up the output pulse counts per one motor revolution for each OA and OB with the Pr44 setup. Therefore the pulse output resolution after quadruple can be obtained from the formula below.</p> <p style="text-align: center;">The pulse output resolution per one revolution                      = Pr44 (Numerator of pulse output division) X4</p> </div> <p>• <b>Pr45≠0 :</b>                      The pulse output resolution per one revolution can be divided by any ration according to the formula below.</p> <p style="text-align: center;">Pulse output resolution per one revolution <math>\frac{\text{Pr44 (Numerator of pulse output division)}}{\text{Pr45 (Denominator of pulse output division)}} \times \text{Encoder resolution}</math></p> <p>&lt;Cautions&gt;</p> <ul style="list-style-type: none"> <li>• The encoder resolution is 131072 [P/r] for the 17-bit absolute encoder, and 10000 [P/r] for the 5-wire 2500P/r incremental encoder.</li> <li>• The pulse output resolution per one revolution cannot be greater than the encoder resolution.                      (In the above setup, the pulse output resolution equals to the encoder resolution.)</li> <li>• Z-phase is fed out once per one revolution of the motor.</li> </ul> <p>When the pulse output resolution obtained from the above formula is multiple of 4, Z-phase synchronizes with A-phase. In other case, the Z-phase width equals to output with the encoder resolution, and becomes narrower than A-phase, hence does not synchronize with A-phase.</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px; width: 45%;"> <p>when encoder resolution x <math>\frac{\text{Pr44}}{\text{Pr45}}</math> is multiple of 4</p> <p style="text-align: center;">Synchronized</p> </div> <div style="border: 1px solid black; padding: 5px; width: 45%;"> <p>when encoder resolution x <math>\frac{\text{Pr44}}{\text{Pr45}}</math> is not multiple of 4</p> <p style="text-align: center;">Not-synchronized</p> </div> </div>
45 *	Denominator of pulse output division	0 – 32767 <0>	

Connection and Setup of Velocity Control Mode

<Notes>

- For parameters which No. have a suffix of "\*", changed contents will be validated when you turn on the control power.

# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Function/Content																											
46 *	Reversal of pulse output logic	0 – 3 <0>	<p>You can set up the B-phase logic and the output source of the pulse output (X5 OB+ : Pin-48, OB- : Pin-49). With this parameter, you can reverse the phase relation between the A-phase pulse and the B-phase pulse by reversing the B-phase logic.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>A-phase (OA)</th> <th>at motor CCW rotation</th> <th>at motor CW rotation</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;, 2</td> <td>B-phase(OB) non-reversal</td> <td></td> <td></td> </tr> <tr> <td>1, 3</td> <td>B-phase(OB) reversal</td> <td></td> <td></td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Pr46</th> <th>B-phase logic</th> <th>Output source</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td>Non-reversal</td> <td>Encoder position</td> </tr> <tr> <td>1</td> <td>Reversal</td> <td>Encoder position</td> </tr> <tr> <td>2 *1</td> <td>Non-reversal</td> <td>External scale position</td> </tr> <tr> <td>3 *1</td> <td>Reversal</td> <td>External scale position</td> </tr> </tbody> </table> <p>*1 The output source of Pr46=2, 3 is valid onlt at full-closed control.</p>	Setup value	A-phase (OA)	at motor CCW rotation	at motor CW rotation	<0>, 2	B-phase(OB) non-reversal			1, 3	B-phase(OB) reversal			Pr46	B-phase logic	Output source	<0>	Non-reversal	Encoder position	1	Reversal	Encoder position	2 *1	Non-reversal	External scale position	3 *1	Reversal	External scale position
Setup value	A-phase (OA)	at motor CCW rotation	at motor CW rotation																											
<0>, 2	B-phase(OB) non-reversal																													
1, 3	B-phase(OB) reversal																													
Pr46	B-phase logic	Output source																												
<0>	Non-reversal	Encoder position																												
1	Reversal	Encoder position																												
2 *1	Non-reversal	External scale position																												
3 *1	Reversal	External scale position																												

## Parameters for Velocity and Torque Control

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content
50	Input gain of speed command	10 – 2000 <500>	(r/min)/V	<p>You can set up the relation between the voltage applied to the speed command input (SPR : CN X5, Pin-14) and the motor speed.</p> <ul style="list-style-type: none"> <li>You can set up a "slope" of the relation between the command input voltage and the motor speed, with Pr50.</li> <li>Default is set to Pr50=500 [r/min], hence input of 6V becomes 3000r/min.</li> </ul> <p><b>&lt;Cautions&gt;</b></p> <ol style="list-style-type: none"> <li>Do not apply more than <math>\pm 10V</math> to the speed command input (SPR).</li> <li>When you compose a position loop outside of the driver while you use the driver in velocity control mode, the setup of Pr50 gives larger variance to the overall servo system. Pay an extra attention to oscillation caused by larger setup of Pr50.</li> </ol>

### <Notes>

- For parameters which No. have a suffix of "\*\*", changed contents will be validated when you turn on the control power.




# [Connection and setup of velocity control mode]

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content														
51	Reversal of speed command input	0 – 1 <1>	–	<p>You can reverse the polarity of the speed command input signal (SPR:CN X5, Pin-14). Use this function when you want to change the motor rotational direction without changing the polarity of the command signal from the host.</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Motor rotating direction</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>CCW direction with (+) command (viewed from the motor shaft end)</td> </tr> <tr> <td>&lt;1&gt;</td> <td>CW direction with (+) command (viewed from the motor shaft end)</td> </tr> </tbody> </table> <p><b>&lt;Notes&gt;</b></p> <ul style="list-style-type: none"> <li>• Default of this parameter is 1, and the motor turns to CW with (+) signal, this has compatibility to existing MINAS series driver.</li> <li>• When Pr06 (ZEROSPD) is set to 2, this parameter becomes invalid.</li> </ul> <p><b>&lt;Caution&gt;</b></p> <p>When you compose the servo drive system with this driver set to velocity control mode and external positioning unit, the motor might perform an abnormal action if the polarity of the speed command signal from the unit and the polarity of this parameter setup does not match.</p>	Setup value	Motor rotating direction	0	CCW direction with (+) command (viewed from the motor shaft end)	<1>	CW direction with (+) command (viewed from the motor shaft end)								
Setup value	Motor rotating direction																	
0	CCW direction with (+) command (viewed from the motor shaft end)																	
<1>	CW direction with (+) command (viewed from the motor shaft end)																	
52	Speed command offset	–2047 – 2047 <0>	0.3mV	<ul style="list-style-type: none"> <li>• You can make an offset adjustment of analog speed command (SPR : CN X5, Pin-14) with this parameter.</li> <li>• The offset volume is 0.3mV per setup value of "1".</li> <li>• There are 2 offset methods, (1) Manual adjustment and (2) Automatic adjustment.</li> </ul> <table border="1"> <tr> <td colspan="2">1) Manual adjustment</td> </tr> <tr> <td>•</td> <td>When you make an offset adjustment with the driver alone, Enter 0 V exactly to the speed command input (SPR/TRQR), (or connect to the signal ground), then set this parameter up so that the motor may not turn.</td> </tr> <tr> <td>•</td> <td>when you compose a position loop with the host,</td> </tr> <tr> <td>•</td> <td>Set this parameter up so that the deviation pulse may be reduced to 0 at the Servo-Lock status.</td> </tr> <tr> <td colspan="2">2) Automatic adjustment</td> </tr> <tr> <td>•</td> <td>For the details of operation method at automatic offset adjustment mode, refer to P.73, "Auxiliary Function Mode" of Preparation.</td> </tr> <tr> <td>•</td> <td>Result after the execution of the automatic offset function will be reflected in this parameter, Pr52.</td> </tr> </table>	1) Manual adjustment		•	When you make an offset adjustment with the driver alone, Enter 0 V exactly to the speed command input (SPR/TRQR), (or connect to the signal ground), then set this parameter up so that the motor may not turn.	•	when you compose a position loop with the host,	•	Set this parameter up so that the deviation pulse may be reduced to 0 at the Servo-Lock status.	2) Automatic adjustment		•	For the details of operation method at automatic offset adjustment mode, refer to P.73, "Auxiliary Function Mode" of Preparation.	•	Result after the execution of the automatic offset function will be reflected in this parameter, Pr52.
1) Manual adjustment																		
•	When you make an offset adjustment with the driver alone, Enter 0 V exactly to the speed command input (SPR/TRQR), (or connect to the signal ground), then set this parameter up so that the motor may not turn.																	
•	when you compose a position loop with the host,																	
•	Set this parameter up so that the deviation pulse may be reduced to 0 at the Servo-Lock status.																	
2) Automatic adjustment																		
•	For the details of operation method at automatic offset adjustment mode, refer to P.73, "Auxiliary Function Mode" of Preparation.																	
•	Result after the execution of the automatic offset function will be reflected in this parameter, Pr52.																	
53	1st speed of speed setup	–20000 – 20000 <0>	r/min	<p>When the internal speed setup is validated with parameter Pr05, "Switching of internal or external speed setup", you can set up 1st to 4th speed into Pr53 -56, 5th to 8th speed into Pr74-77 in direct unit of [r/min].</p> <p><b>&lt;Caution&gt;</b></p> <ul style="list-style-type: none"> <li>• The polarity of the setup value represents that of the internal command speed.</li> </ul> <table border="1"> <tr> <td>+</td> <td>Command to CCW (viewed from the motor shaft end)</td> </tr> <tr> <td>–</td> <td>Command to CW (viewed from the motor shaft end)</td> </tr> </table>	+	Command to CCW (viewed from the motor shaft end)	–	Command to CW (viewed from the motor shaft end)										
+	Command to CCW (viewed from the motor shaft end)																	
–	Command to CW (viewed from the motor shaft end)																	
54	2nd speed of speed setup																	
55	3rd speed of speed setup																	
56	4th speed of speed setup																	
74	5th speed of speed setup	–20000 – 20000 <0>	r/min	<ul style="list-style-type: none"> <li>• The absolute value of the parameter setup is limited with Pr73 (Setup of over-speed level)</li> </ul>														
75	6th speed of speed setup																	
76	7th speed of speed setup																	
77	8th speed of speed setup																	
57	Setup of speed command filter	0 – 6400 <0>	0.01ms	<p>You can set up the time constant of the primary delay filter to the analog speed command/analog torque command/analog velocity control (SPR : CN X5, Pin-14)</p>														

# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content				
58	Acceleration time setup	0 – 5000 <0>	2ms/ (1000r/min)	<p>You can make the velocity control while adding acceleration and deceleration command to the speed command inside of the driver. With this function, you can make a soft-start when you enter the step-speed command and when you use with the internal speed setup.</p>  <table border="1" data-bbox="1037 392 1452 481"> <tr> <td>ta</td> <td>[Pr58] x 2ms/(1000r/min)</td> </tr> <tr> <td>td</td> <td>[Pr59] x 2ms/(1000r/min)</td> </tr> </table>	ta	[Pr58] x 2ms/(1000r/min)	td	[Pr59] x 2ms/(1000r/min)
ta	[Pr58] x 2ms/(1000r/min)							
td	[Pr59] x 2ms/(1000r/min)							
59	Deceleration time setup	0 – 5000 <0>	2ms/ (1000r/min)	<p><b>&lt;Caution&gt;</b> Do not use these acceleration/deceleration time setup when you use the external position loop. (Set up both Pr58 and Pr59 to 0.)</p>				
5A	Sigmoid acceleration/ deceleration time setup	0 – 500 <0>	2ms	<p>In order to obtain a smooth operation, you can set up the quasi sigmoid acceleration/deceleration in such application as linear acceleration/ deceleration where acceleration variation is large at starting/stopping to cause a strong shock.</p>  <ol style="list-style-type: none"> <li>1. Set up acceleration/deceleration for basic linear portion with Pr58 and Pr59</li> <li>2. Set up sigmoid time with time width centering the inflection point of linear acceleration/deceleration with Pr5A. (unit : 2ms)</li> </ol> <p>             ta : Pr58      Use with the setup of              td : Pr59      <math>\frac{ta}{2} &gt; ts</math>, <math>ts</math>, and <math>\frac{td}{2} &gt; ts</math>              ts : Pr5A         </p>				
5E	1st torque limit setup	0 – 500 <500> *2	%	<p>You can set up the limit value of the motor output torque (Pr5E : 1st torque, Pr5F : 2nd torque). For the torque limit selection, refer to Pr03 (Torque limit selection).</p> <p>This torque limit function limits the max. motor torque inside of the driver with parameter setup. In normal operation, this driver permits approx. 3 times larger torque than the rated torque instantaneously. If this 3 times bigger torque causes any trouble to the load (machine) strength, you can use this function to limit the max. torque.</p> <ul style="list-style-type: none"> <li>• Setup value is to be given in % against the rated torque.</li> <li>• Right fig. shows example of 150% setup with Pr03=1.</li> <li>• Pr5E limits the max. torque for both CCW and CW directions.</li> </ul> 				
5F	2nd torque limit setup	0 – 500 <500> *2	%		<p><b>&lt;Caution&gt;</b> You cannot set up a larger value to this parameter than the default setup value of "Max. output torque setup" of System parameter (which you cannot change through operation with PANATERM® or panel). Default value varies depending on the combination of the motor and the driver. For details, refer to P.57, "Setup of Torque Limit" of Preparation.</p>			

**<Notes>**

- For parameters which No. have a suffix of "\*", changed contents will be validated when you turn on the control power.
- For parameters which default. has a suffix of "\*2", value varies depending on the combination of the driver and the motor.

# [Connection and setup of velocity control mode]

## Parameters for Sequence

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content						
61	Zero-speed	10 – 20000 <50>	r/min	<p>You can set up the timing to feed out the zero-speed detection output signal (ZSP : CN X5, Pin-12 or TCL : CN X5, Pin-40) in rotational speed [r/min]. The zero-speed detection signal (ZSP) will be fed out when the motor speed falls below the setup of this parameter, Pr61. In-speed (Speed coincidence) signal (V-COIN) will be fed out when the difference between the speed command and the motor speed falls below the setup of this parameter, Pr61.</p> <ul style="list-style-type: none"> <li>• The setup of P61 is valid for both CCW and CW direction regardless of the motor rotating direction.</li> <li>• There is hysteresis of 10 [r/min].</li> </ul>						
62	At-speed (Speed arrival)	10 – 20000 <50>	r/min	<p>You can set up the timing to feed out the At-speed signal (COIN+ : CN X5, Pin-39, COIN- : CN X5, Pin-38) At-speed (Speed arrival) (COIN) will be fed out when the motor speed exceeds the setup speed of this parameter, Pr62</p> <ul style="list-style-type: none"> <li>• The setup of P62 is valid for both CCW and CW direction regardless of the motor rotational direction.</li> <li>• There is hysteresis of 10 [r/min].</li> </ul>						
65	LV trip selection at main power OFF	0 – 1 <1>	–	<p>You can select whether or not to activate Err13 (Main power under-voltage protection) function while the main power shutoff continues for the setup of Pr6D (Main power-OFF detection time).</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Action of main power low voltage protection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>When the main power is shut off during Servo-ON, Err13 will not be triggered and the driver turns to Servo-OFF. The driver returns to Servo-ON again after the main power resumption.</td> </tr> <tr> <td>&lt;1&gt;</td> <td>When the main power is shut off during Servo-ON, the driver will trip due to Err13 (Main power low voltage protection).</td> </tr> </tbody> </table> <p><b>&lt;Caution&gt;</b> This parameter is invalid when Pr6D (Detection time of main power OFF)=1000. Err13 (Main power under-voltage protection) is triggered when setup of P66D is long and P-N voltage of the main converter falls below the specified value before detecting the main power shutoff, regardless of the Pr65 setup. Refer to P.42, "Timing Chart-At Power-ON" of Preparation as well.</p>	Setup value	Action of main power low voltage protection	0	When the main power is shut off during Servo-ON, Err13 will not be triggered and the driver turns to Servo-OFF. The driver returns to Servo-ON again after the main power resumption.	<1>	When the main power is shut off during Servo-ON, the driver will trip due to Err13 (Main power low voltage protection).
Setup value	Action of main power low voltage protection									
0	When the main power is shut off during Servo-ON, Err13 will not be triggered and the driver turns to Servo-OFF. The driver returns to Servo-ON again after the main power resumption.									
<1>	When the main power is shut off during Servo-ON, the driver will trip due to Err13 (Main power low voltage protection).									

# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content																																														
66 *	Sequence at over-travel inhibit	0 – 2 <0>	–	<p>You can set up the running condition during deceleration or after stalling, while over-travel inhibit input (CCWL : Connector CN X5, Pin-9 or CWL : Connector CN X5, Pin-8) is valid</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>During deceleration</th> <th>After stalling</th> <th>Deviation counter content</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td>Dynamic brake action</td> <td>Torque command=0 towards inhibited direction</td> <td>Hold</td> </tr> <tr> <td>1</td> <td>Torque command=0 towards inhibited direction</td> <td>Torque command=0 towards inhibited direction</td> <td>Hold</td> </tr> <tr> <td>2</td> <td>Emergency stop</td> <td>Torque command=0 towards inhibited direction</td> <td>Clears before/ after deceleration</td> </tr> </tbody> </table> <p><b>&lt;Caution&gt;</b> In case of the setup value of 2, torque limit during deceleration will be limited by the setup value of Pr6E (Torque setup at emergency stop ).</p>	Setup value	During deceleration	After stalling	Deviation counter content	<0>	Dynamic brake action	Torque command=0 towards inhibited direction	Hold	1	Torque command=0 towards inhibited direction	Torque command=0 towards inhibited direction	Hold	2	Emergency stop	Torque command=0 towards inhibited direction	Clears before/ after deceleration																														
Setup value	During deceleration	After stalling	Deviation counter content																																															
<0>	Dynamic brake action	Torque command=0 towards inhibited direction	Hold																																															
1	Torque command=0 towards inhibited direction	Torque command=0 towards inhibited direction	Hold																																															
2	Emergency stop	Torque command=0 towards inhibited direction	Clears before/ after deceleration																																															
67	Sequence at main power OFF	0 – 9 <0>	–	<p>When Pr65 (LV trip selection at main power OFF) is 0, you can set up, 1) the action during deceleration and after stalling 2) the clearing of deviation counter content after the main power is shut off.</p> <table border="1"> <thead> <tr> <th rowspan="2">Setup value</th> <th colspan="2">Action</th> <th rowspan="2">Deviation counter content</th> </tr> <tr> <th>During deceleration</th> <th>After stalling</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td>DB</td> <td>DB</td> <td>Clear</td> </tr> <tr> <td>1</td> <td>Free-run</td> <td>DB</td> <td>Clear</td> </tr> <tr> <td>2</td> <td>DB</td> <td>Free-run</td> <td>Clear</td> </tr> <tr> <td>3</td> <td>Free-run</td> <td>Free-run</td> <td>Clear</td> </tr> <tr> <td>4</td> <td>DB</td> <td>DB</td> <td>Hold</td> </tr> <tr> <td>5</td> <td>Free-run</td> <td>DB</td> <td>Hold</td> </tr> <tr> <td>6</td> <td>DB</td> <td>Free-run</td> <td>Hold</td> </tr> <tr> <td>7</td> <td>Free-run</td> <td>Free-run</td> <td>Hold</td> </tr> <tr> <td>8</td> <td>Emergency stop</td> <td>D</td> <td>Clear</td> </tr> <tr> <td>9</td> <td>Emergency stop</td> <td>Free-run</td> <td>Clear</td> </tr> </tbody> </table> <p>(DB: Dynamic Brake action) <b>&lt;Caution&gt;</b> In case of the setup value of 8 or 9, torque limit during deceleration will be limited by the setup value of Pr6E (Torque setup at emergency stop).</p>	Setup value	Action		Deviation counter content	During deceleration	After stalling	<0>	DB	DB	Clear	1	Free-run	DB	Clear	2	DB	Free-run	Clear	3	Free-run	Free-run	Clear	4	DB	DB	Hold	5	Free-run	DB	Hold	6	DB	Free-run	Hold	7	Free-run	Free-run	Hold	8	Emergency stop	D	Clear	9	Emergency stop	Free-run	Clear
Setup value	Action		Deviation counter content																																															
	During deceleration	After stalling																																																
<0>	DB	DB	Clear																																															
1	Free-run	DB	Clear																																															
2	DB	Free-run	Clear																																															
3	Free-run	Free-run	Clear																																															
4	DB	DB	Hold																																															
5	Free-run	DB	Hold																																															
6	DB	Free-run	Hold																																															
7	Free-run	Free-run	Hold																																															
8	Emergency stop	D	Clear																																															
9	Emergency stop	Free-run	Clear																																															
68	Sequence at alarm	0 – 3 <0>	–	<p>You can set up the action during deceleration or after stalling when some error occurs while either one of the protective functions of the driver is triggered.</p> <table border="1"> <thead> <tr> <th rowspan="2">Setup value</th> <th colspan="2">Action</th> <th rowspan="2">Deviation counter content</th> </tr> <tr> <th>During deceleration</th> <th>After stalling</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt;</td> <td>DB</td> <td>DB</td> <td>Hold</td> </tr> <tr> <td>1</td> <td>Free-run</td> <td>DB</td> <td>Hold</td> </tr> <tr> <td>2</td> <td>DB</td> <td>Free-run</td> <td>Hold</td> </tr> <tr> <td>3</td> <td>Free-run</td> <td>Free-run</td> <td>Hold</td> </tr> </tbody> </table> <p>(DB: Dynamic Brake action) <b>&lt;Caution&gt;</b> The content of the deviation counter will be cleared when clearing the alarm. Refer to P.43, "Timing Chart (When an error (alarm) occurs (at Servo-ON command status))" of Preparation.</p>	Setup value	Action		Deviation counter content	During deceleration	After stalling	<0>	DB	DB	Hold	1	Free-run	DB	Hold	2	DB	Free-run	Hold	3	Free-run	Free-run	Hold																								
Setup value	Action		Deviation counter content																																															
	During deceleration	After stalling																																																
<0>	DB	DB	Hold																																															
1	Free-run	DB	Hold																																															
2	DB	Free-run	Hold																																															
3	Free-run	Free-run	Hold																																															

## <Notes>

- For parameters which No. have a suffix of "\*", changed contents will be validated when you turn on the control power.

# [Connection and setup of velocity control mode]

Standard default : <>

PrNo.	Title	Setup range	Unit	Function/Content
69	Sequence at Servo-Off	0 – 9 <0>	–	<p>You can set up,</p> <ol style="list-style-type: none"> <li>the action during deceleration and after stalling</li> <li>the clearing of deviation counter content,</li> </ol> <p>after turning to Servo-OFF (SRV-ON signal : CN X5, Pin-29 is turned from ON to OFF)</p> <p>The relation between the setup value of Pr69 and the action/deviation counter clearance is same as that of Pr67 (Sequence at Main Power Off)</p> <p>Refer to P.44, "Timing Chart"-Servo-ON/OFF action while the motor is at stall" of Preparation as well.</p>
6A	Setup of mechanical brake action at stall	0 – 100 <0>	2ms	<p>You can set up the time from when the brake release signal (BRK-OFF : CN X5, Pin-10 and 11) turns off to when the motor is de-energized (Servo-free), when the motor turns to Servo-OFF while the motor is at stall.</p> <div style="border: 1px solid black; padding: 5px;"> <ul style="list-style-type: none"> <li>Set up to prevent a micro-travel/ drop of the motor (work) due to the action delay time (tb) of the brake</li> <li>After setting up <math>Pr6a \geq tb</math>, then compose the sequence so as the driver turns to Servo-OFF after the brake is actually activated.</li> </ul> </div> <p>Refer to P.44, "Timing Chart"-Servo-ON/OFF Action While the Motor Is at Stall" of Preparation as well.</p>
6B	Setup of mechanical brake action at running	0 – 100 <0>	2ms	<p>You can set up time from when detecting the off of Servo-ON input signal (SRV-ON : CN X5, Pin-29) is to when external brake release signal (BRK-OFF : CN X5, Pin-10 and 11) turns off, while the motor turns to servo off during the motor in motion.</p> <div style="border: 1px solid black; padding: 5px;"> <ul style="list-style-type: none"> <li>Set up to prevent the brake deterioration due to the motor running.</li> <li>At Servo-OFF during the motor is running, tb of the right fig. will be a shorter one of either Pr6B setup time, or time lapse till the motor speed falls below 30r/min.</li> </ul> </div> <p>Refer to P.45, "Timing Chart"-Servo-ON/OFF action while the motor is in motion" of Preparation as well.</p>


# Parameter Setup

Standard default : < >

PrNo.	Title	Setup range	Unit	Function/Content															
6C *	Selection of external regenerative resistor	0 – 3 for A, B-frame <3> for B–F-frame <0>	–	<p>With this parameter, you can select either to use the built-in regenerative resistor of the driver, or to separate this built-in regenerative resistor and externally install the regenerative resistor (between RB1 and RB2 of Connector CN X2 in case of A-D-frame, between P and B2 of terminal block in case of E-F-frame).</p> <table border="1"> <thead> <tr> <th>Setup value</th> <th>Regenerative resistor to be used</th> <th>Regenerative processing and regenerative resistor overload</th> </tr> </thead> <tbody> <tr> <td>&lt;0&gt; (C, D, E and F-frame)</td> <td>Built-in resistor</td> <td>Regenerative processing circuit will be activated and regenerative resistor overload protection will be triggered according to the built-in resistor (approx. 1% duty).</td> </tr> <tr> <td>1</td> <td>External resistor</td> <td>The driver trips due to regenerative overload protection (Err18), when regenerative processing circuit is activated and its active ratio exceeds 10%.</td> </tr> <tr> <td>2</td> <td>External resistor</td> <td>Regenerative processing circuit is activated, but no regenerative over-load protection is triggered.</td> </tr> <tr> <td>&lt;3&gt; (A, B-frame)</td> <td>No resistor</td> <td>Both regenerative processing circuit and regenerative protection are not activated, and built-in capacitor handles all regenerative power.</td> </tr> </tbody> </table> <p><b>&lt;Remarks&gt;</b> Install an external protection such as thermal fuse when you use the external regenerative resistor. Otherwise, the regenerative resistor might be heated up abnormally and result in burnout, regardless of validation or invalidation of regenerative over-load protection.</p> <p><b>&lt;Caution&gt;</b> When you use the built-in regenerative resistor, never to set up other value than 0. Don't touch the external regenerative resistor. External regenerative resistor gets very hot, and might cause burning.</p>	Setup value	Regenerative resistor to be used	Regenerative processing and regenerative resistor overload	<0> (C, D, E and F-frame)	Built-in resistor	Regenerative processing circuit will be activated and regenerative resistor overload protection will be triggered according to the built-in resistor (approx. 1% duty).	1	External resistor	The driver trips due to regenerative overload protection (Err18), when regenerative processing circuit is activated and its active ratio exceeds 10%.	2	External resistor	Regenerative processing circuit is activated, but no regenerative over-load protection is triggered.	<3> (A, B-frame)	No resistor	Both regenerative processing circuit and regenerative protection are not activated, and built-in capacitor handles all regenerative power.
Setup value	Regenerative resistor to be used	Regenerative processing and regenerative resistor overload																	
<0> (C, D, E and F-frame)	Built-in resistor	Regenerative processing circuit will be activated and regenerative resistor overload protection will be triggered according to the built-in resistor (approx. 1% duty).																	
1	External resistor	The driver trips due to regenerative overload protection (Err18), when regenerative processing circuit is activated and its active ratio exceeds 10%.																	
2	External resistor	Regenerative processing circuit is activated, but no regenerative over-load protection is triggered.																	
<3> (A, B-frame)	No resistor	Both regenerative processing circuit and regenerative protection are not activated, and built-in capacitor handles all regenerative power.																	
6D *	Detection time of main power off	35 – 1000 <35>	2ms	<p>You can set up the time to detect the shutoff while the main power is kept shut off continuously. The main power off detection is invalid when you set up this to 1000.</p>															
6E	Torque setup at emergency stop	0 – 500 <0>	%	<p>You can set up the torque limit in case of emergency stop as below.</p> <ul style="list-style-type: none"> <li>• During deceleration of over-travel inhibit with the setup 2 of Pr66 (Sequence at over-travel inhibit input)</li> <li>• During deceleration with the setup of 8 or 9 of Pr67 (Sequence at main power off)</li> <li>• During deceleration with the setup of 8 or 9 of Pr69 (Sequence at Servo-OFF)</li> </ul> <p>Normal torque limit is used by setting this to 0.</p>															
70	Setup of position deviation excess	0 – 32767 <25000>	256 x resolution	<ul style="list-style-type: none"> <li>• You can set up the excess range of position deviation.</li> <li>• Set up with the encoder pulse counts at the position control and with the external scale pulse counts at the full-closed control.</li> <li>• Err24 (Error detection of position deviation excess) becomes invalid when you set up this to 0.</li> </ul>															
72	Setup of over-load level	0 – 500 <0>	%	<ul style="list-style-type: none"> <li>• You can set up the over-load level. The overload level becomes 115 [%] by setting up this to 0.</li> <li>• Use this with 0 setup in normal operation. Set up other value only when you need to lower the over-load level.</li> <li>• The setup value of this parameter is limited by 115[%] of the motor rating.</li> </ul>															
73	Setup of over-speed level	0 – 20000 <0>	r/min	<ul style="list-style-type: none"> <li>• You can set up the over-speed level. The over-speed level becomes 1.2 times of the motor max. speed by setting up this to 0.</li> <li>• Use this with 0 setup in normal operation. Set up other value only when you need to lower the over-speed level.</li> <li>• The setup value of this parameter is limited by 1.2 times of the motor max. speed.</li> </ul> <p><b>&lt;Caution&gt;</b> The detection error against the setup value is <math>\pm 3</math> [r/min] in case of the 7-wire absolute encoder, and <math>\pm 36</math> [r/min] in case of the 5-wire incremental encoder.</p>															

## <Notes>

- For parameters which No. have a suffix of "\*", changed contents will be validated when you turn on the control power.



## [Connection and Setup of Torque Control Mode]

	page
<b>Control Block Diagram of Torque Control Mode ....</b>	<b>160</b>
<b>Wiring to the Connector, CN X5 .....</b>	<b>161</b>
Wiring Example to the Connector, CN X5 .....	161
Interface Circuit .....	162
Input Signal and Pin No. of the Connector, CN X5 .....	164
Output Signal and Pin No. of the Connector, CN X5 .....	168
<b>Trial Run (JOG Run) at Torque Control Mode .....</b>	<b>171</b>
Inspection Before Trial Run .....	171
Trial Run by Connecting the Connector, CN X5 .....	171
<b>Real-Time Auto-Gain Tuning .....</b>	<b>172</b>
Outline .....	172
Applicable Range .....	172
How to Operate .....	172
Parameters Which are Automatically Set .....	173
<b>Parameter Setup .....</b>	<b>174</b>
Parameters for Functional Selection .....	174
Parameters for Adjustment of Time Constant of Gains and Filters .....	177
Parameters for Auto-Gain Tuning .....	178
Parameters for Adjustment (2nd Gain Switching Function) .....	179
Parameters for Position Control .....	181
Parameters for Velocity/Torque Control .....	183
Parameters for Sequence .....	185